


Hardware Manual



Quad Port RS232 & Lynx 8 Port RS232

4.6 EDITION JANUARY 1998

Guarantee.

FULL 36 MONTHS GUARANTEE.

We guarantee your Serial Port Card for a full 36 months from purchase, parts and labour, provided it has been used in the specified manner. In the unlikely event of failure return your interface to your Dealer, with proof of purchase, who will determine whether to repair or replace this product with an equivalent unit.


COPYRIGHT.

COPYRIGHT © 1985-1998.

All rights reserved. No part of this hardware, circuitry or manual may be duplicated, copied, transmitted or reproduced in any way without the prior written consent of the Manufacturer.

Due to the manufacturers commitment to quality, software is subject to continuous improvements: information regarding upgrades can be obtained from your dealer.

Serial Solutions is supplied to you by



ACKNOWLEDGEMENTS.

IBM, COMPAQ, Hewlett Packard, H.P. and EPSON are trademarks of the relevant companies. OS/2 and Microchannel Architecture are trademarks of IBM. Windows is a trademark of Microsoft.

AT QUAD 4 PORT AND AT LYNX 8 PORT RS232 MANUAL

Note: This manual documents the surface mount (revision 5) AT QUAD 4 PORT RS232 and surface mount (revision 8) AT LYNX 8 PORT RS232.

OUTLINE CONTENTS

Chapter 1. Serial Solutions Software

Chapter 2. At Quad 4 Port RS232 Hardware
Configuration

Chapter 3. At Lynx 8 Port RS232 Hardware
Configuration

Chapter 4. How to install your card into the PC

Chapter 5. AT Quad 4 Port and AT Lynx 8 Port Software
Configuration

Chapter 6. Quad and Lynx Shared Interrupt Mechanisms

Chapter 7. RS232 port Cabling

THE LAYOUT OF THIS MANUAL

Chapter 1 - Serial Solutions Software, is an overview of the companion software package that comes with the Quad and Lynx cards.

Chapter 2 - AT Quad 4 Port Hardware Configuration, shows how to configure the settings of the AT QUAD RS232. Details of COM, IRQ and Shared Interrupt mechanisms are given.

Chapter 3 - AT Lynx 8 Port Hardware Configuration, shows how to configure the settings of the AT LYNX 8 Port RS232. Details of COM, IRQ and Shared Interrupt mechanisms are given.

Chapter 4 - How to install your card into a PC, after configuration a step by step guide to installing the configured card in PC expansion slots.

Chapter 5 - AT Quad 4 Port and AT Lynx 8 Port Software Configuration Guide, details on how to setup the serial *solutions software provided with the cards in Windows 3.x, Windows 95, Windows NT, OS/2.x, OS/2 Warp and SCO Unix and Xenix Kernal Resident Support.

Chapter 6 - Quad and Lynx Shared Interrupt Mechanisms, shows you how to link several Quad and/or Lynx Cards together so as to use only one interrupt line, multi card ID settings and the Shared Interrupt Status Register operation.

Chapter 7 - RS232 Port Cabling, gives standard 9 and 25 Pin outs of RS232 ports, cabling and connections. Showing how to make up a loop back connector for RS232 port self-tests and how to wire a 9 to 25 pin adapter. The pinouts of Quad 37 way and Lynx 78 way connectors and cables are also given.

Index

CHAPTER 1	1
Introduction.	1
Introducing Serial Solution Software.	1
Serial Solutions For DOS.....	1
Serial Solutions For Windows 3.x.....	3
Serial Solutions For Windows 95.....	4
Serial Solutions For Windows NT.....	4
Complete Documentation and Technical Backup.	4
CHAPTER 2	6
Introduction.	6
AT QUAD 4 PORT RS232 Card Features.	6
Configuring the AT Quad 4 Port RS232.....	11
Serial Port Configuration.	13
Serial Port Setup.	13
Individual Serial Port Configuration	13
Serial Port Bank Address Configuration.....	14
Serial Port IRQ Interrupt Jumper Selection.	21
Shared Interrupt Setup.	23
Shared IRQ Interrupt Jumper Selection.....	29
Shared Interrupt Mechanism.	30
One Quad Card Systems.	30
CHAPTER 3	32
Introduction.	32
AT LYNX 8 PORT RS232 Card Features.....	32
Configuring The AT LYNX 8 Port RS232.....	37
Serial Port Configuration.	39
Serial Port I/O Configuration.	39
Individual Serial Port Configuration	39
Serial Port Bank Address Configuration.....	41
Serial Port IRQ Interrupt Jumper Selection.	47
Shared Interrupt Setup.	49
Shared IRQ Interrupt Jumper Selection.....	55
Shared Interrupt Mechanism.	56

One Lynx Card Systems.....	56
CHAPTER 4	58
Serial Card Installation.....	58
Problems!.....	61
CHAPTER 5	62
Introduction	62
Informing The PC Of The Port Address.	62
Settings for DOS Software.....	65
Serial Solution Configuration For Lynx Cards.	65
Driver Defaults.	79
Serial Solutions Installation for Windows 3.x	81
Serial Port Installation	82
Changing Serial Port Settings	86
Shared Interrupt Serial Port Setup Procedure.	86
Deleting Ports in Windows.	89
Restarting Windows.....	89
Serial Solutions Installation for Windows 95 & 98.....	90
Multiport Card Settings in Windows 95 & 98.....	95
Changing COM Port Numbers in Windows 95 & 98.....	97
Multiport Card Port Settings In Windows 95 & 98.	98
Restarting Windows.....	100
Serial Solutions Installation for Windows NT 3.51 & 4	102
Checking Windows NT 4 I/O Usage	102
Checking Windows NT 3.51 I/O Usage	103
Configuring and Installing the Serial Card	104
Installing the Serial Solutions Software	105
Issues in Configuring the Serial Solutions Software.....	105
Configuring the Serial Solutions Software	106
Add Another Multiport Card.....	109
Configuring Ports	110
Shared Settings	112
Card Type Differences.....	112
Configuring Ports 5 to 8 (8 Port Cards Only).....	113
Completing Card Setup.....	114

AT QUAD AND LYNX RS232	Introduction
Modifying Settings for a Multiport Card.....	116
Deleting Settings for a Multiport Card.....	118
Deleting All Multiport Card Settings	119
Configuring Ports in OS/2 Version 2.x and OS/2 Warp.....	121
Configuring Ports in SCO Unix / Xenix.....	122
Optional Custom Driver and Installation Script.....	122
AT Quad 4 and the AT Lynx Under SCO Unix.	122
SCO Unix/ Xenix Jumper Settings.....	123
CHAPTER 6	126
Introduction.	126
Digiboard Compatibility.	126
Why Do We Need A Shared Interrupt Mechanism?	126
Shared Interrupt Status Register.....	127
Last Card Settings.....	128
One Lynx Card Systems.....	128
Multiple Card Setup.....	129
Mixing 4 Port and 8 Port Cards.....	132
Two Card Systems.....	132
Three Card Systems.....	133
Four Or More Card Systems.....	134
Multi Card Shared Interrupt Status Register.....	135
CHAPTER 7	139
Introduction.....	139
The RS232 Standard.....	139
Serial Port Pin Outs.....	140
9 Pin D Serial Port RS232 Cables.....	140
9 Pin D Serial Port Connection To Another PC.....	141
9 Pin D Serial Port Loop Back Connector.....	143
The Quad Cable Pinouts.....	146
The Lynx Card Octopus Cable Pinouts.....	148
Index.....	152

CHAPTER 1

SERIAL SOLUTION SOFTWARE.

Introduction.

This chapter is a brief advertisement for the OPTIONAL Serial Solutions software package; this is purchased SEPARATELY and is available from YOUR DEALER.

Introducing Serial Solution Software.

The perfect partner for any Serial Port is Serial Solutions Software! Serial Solutions is a fully featured suite of programs designed to squeeze the most from PC serial communications, and is ideal as a teaching aid for you to develop your own serial comms programs.

Serial Solutions is made up of the following components: -

Serial Solutions for DOS
Serial Solutions for Windows 3.x
Serial Solutions for Windows 95
Serial Solutions for Windows NT

All the Serial Solutions drivers have the following features:-

- Drivers for PC FIFO UARTs e.g. 16550 as well as the new improved 32 byte 16650 and 64 byte 16750 UARTs.
- Support for any mix of RS232, RS422 and RS485 handshake schemes.
- Support for wider range of Baud rates and for more than four serial ports.

Serial Solutions For DOS.

Serial Solutions for DOS consists of the following programs: -

NewCOM.sys A device driver, it supports COM1 to COM16, allowing 16 serial ports to be used under DOS. It also includes an interrupt handler for enhanced performance with user definable buffer sizes. Accessible from all DOS languages, it is the heart of the Serial Solution. It has extensive handshaking support, implementing both hardware handshaking using any combination of the DTR, DSR, CTS, RTS and DCD lines and a software handshake using the XON/XOFF protocol.

NewCOM24.sys A device driver providing support for 24 ports.

NewCOM32.sys A device driver providing support for 32 ports.

NewMode.exe A replacement for the DOS 'mode com...' command. NewMode is used to set the serial parameters, including the port address, IRQ line used, the baud rate, parity and data and stop bit options.

e.g. `NEWMODE COM5:38400,E,7,1 01A0 7`

Baud rates supported are from 110 baud to 115,200 baud! Included is a very handy query mode that reports the settings of the various serial ports. Flexible and fast!

EASY programs. The EASY disk contains short, simple to understand and use EASYBAS, EASYC and ASYPAS programs, providing straight forward, file type I/O to serial portswith debug information. Use these FIRST, base your sample applications on them.

Source code, make files and compiled ready to run programs supplied.

TERM programs A suite of larger terminal

emulation programs written in C (Cterm), Assembly language (Aterm), Pascal (Pasterm), BASIC (BASterm) and FORTRAN (FORterm) show how to access the NEWBIOS routines as well as the simple file I/O to ports. They contain many lines of code and are thus harder to grasp. They demonstrate in depth serial port programming in a variety of languages but they are also useful tools for using serial devices.

Comtest.exe

Comtest is a short but invaluable program that is used to check that the serial port at a particular I/O address is functioning correctly and is connected to the particular IRQ line. The program correctly identifies the UART type e.g. non-FIFO, 16550 FIFO, 16550AF FIFO and the improved 16650 32 byte FIFO and 16750 64 byte FIFO's. By employing the built in loop back capability of the PC serial port chip, a full test of the baud rate generator, transmitting and receiving buffer, parity enable and start stop bit is performed. There is no need for a second serial port or a cable when using this utility.

Serial Solutions For Windows 3.x

Serial Solutions for Windows 3.x works with Windows 3.0, 3.1 and 3.11 as well as Windows For Workgroups 3.11.

Serial Solutions for Windows 3.x consists of the following programs: -

Setup.exe

The install routine for the package.

Port.DLL

Enhanced Control Panel applet. Allows configuration of extra serial ports from the Windows Control Panel. Supports single as well as multiport cards using shared interrupts.

BbLynx.drv

Replacement for COMM.DRV.

LynxAPI.dll	Enhancement to the Windows Comms API's allowing support for more than 9 ports.
Term.exe	Terminal program.
EasyCWIN	C source code, project files and ready to run.exe program for an easy to understand Windows terminal program. Learn how to write Windows comms apps correctly the easy way.

Serial Solutions For Windows 95.

Windows 95 has an improved communication API and directly supports up to 255 ports. Our Windows 95 driver supports the shared interrupt mechanism used on our multiport cards. Serial Solutions for Windows 95 consists of the following programs: -

Bbcommsp.inf	The information file to aid the installation process "Have Disk....."
Bbcommui.dll	The DLL and...
BBcomm.vxd	...the virtual device driver providing the shared interrupt handler and dispatch routines.

Serial Solutions For Windows NT.

Windows NT has an improved communication API and directly supports up to 255 ports. No extra driver is necessary for Windows NT to drive multiport cards. Serial Solutions for Windows NT consists of the following programs:-

Multiport.cpl	Control panel applet which allows the simple configuration of all ports on a multiport card simultaneously.
Mulport.hlp	Help file for the above control panel applet.

Complete Documentation and Technical Backup.

We believe in supplying complete documentation with every package we sell. The Serial Solution Software Package is no exception, it has an attractive manual in an A5 binder, containing over 150 pages of in-depth technical detail with comprehensive

indexes and table of contents. We guarantee your Serial Solution Software package or a full 12 months from purchase. A complete technical backup service is available to ensure that you get the maximum performance out of your investment.

CHAPTER 2

AT QUAD 4 PORT RS232 HARDWARE CONFIGURATION.

Introduction.

This chapter explains how to configure the AT QUAD 4 PORT RS232 in a PC compatible, giving details for address and IRQ jumper selection. Detailed instructions are given how to set the address select DIP switches and IRQ jumpers.

This half size RS232 card will fit into both long and short slots, in 8 bit XT or 16 bit AT slots and will work happily in any PC compatible up to and exceeding Pentium II 300 MHz class machines.

AT QUAD 4 PORT RS232 Card Features.


- Four independent RS232 Serial ports.
- Reliable communications up to 50 feet, 15m, and beyond!
- 100% PC Compatible serial port TI or CMD 16C550, up to 115,200 baud.
- Jumper selectable serial port address, COM1- COM4 and many more!
- Jumper selectable interrupt level IRQ 2-7, 10-12, 14 & 15.
- Shared IRQ settings available for all Ports
- Full modem control TXD, RXD, DSR, DCD, DTR, RTS, CTS and RI signals.
- Fully double buffered for reliable asynchronous operation.
- High speed integrated circuitry ensures operation with fast PC's e.g. 300 MHz Pentium II WITHOUT extra wait states.
- 16550 FIFO provides 16-byte input and 16-byte output buffer on each port.

AT QUAD AND LYNX RS232 QUAD Hardware Configuration Guide

The AT QUAD 4 PORT RS232 has the following features:

Baud Rate:	50 Baud to 115200 Baud.
Word Length:	5, 6, 7 or 8 bits.
Parity:	Even, Odd, None, Mark or Space.
Start Bit:	1 start bit always sent.
Stop Bits:	1, (1.5 for 5 bit data word length) or 2.
Clock Input:	1.8432 MHz.


Figure 2-1a). AT Quad 4 Port RS232 Layout
COM1 Present Only



Card Settings	COM1 only
Port#1	COM2
Port#2	COM3
Port#3	COM4
Port#4	Bank
Shared IRQ	3
Bank address	180-198h
SISR address	3A0h
Multi Card	EI + GND
Card ID	0

Last (CARD ID Dip 4)	ON
----------------------	----


**Figure 2-1b). AT Quad 4 Port RS232 Layout
COM1 and COM2 Present**



Card Settings	COM1 & COM2
Port#1	COM3
Port#2	COM4
Port#3	Bank
Port#4	Bank
Shared IRQ	10
Bank address	180-1B8h
SISR address	3A0h
Multi Card	EI + GND
Card ID	0

Last (CARD ID Dip 4)	ON
----------------------	----

**Figure 2-1c). AT Quad 4 Port RS232 Layout
Digiboard PC/4 Configuration**



Card Settings	Digiboard PC/4
Port#1	Bank
Port#2	Bank
Port#3	Bank
Port#4	Bank
Shared IRQ	3
Bank address	100-118h
SISR address	140h
Multi Card	EI + GND
Card ID	0

Last (CARD ID Dip 4)

ON

AT Quad 4 Port Specifications:

Dimensions:	9.5 x 14cm; 3.8 x 5.6in.
I/O Connection:	37 way female D connector to 4 serial ports
Serial Port 1:	9 pin Male D type.
Serial Port 2:	9 pin Male D type.
Serial Port 3:	9 pin Male D type.
Serial Port 4:	9 pin Male D type.

Configuring the AT Quad 4 Port RS232

In the state, it leaves our factory, the AT Quad 4 Port RS232 is ready to plug straight into a PC compatible computer. Unless there is GOOD REASON, do not alter its default setting. However, due to the presence of other serial ports in the PC, your card may need configuring to suit your setup.

If your card needs to be reconfigured it is important to know the settings (particularly IRQ allocations) of any other add on cards / motherboard resources that exist in your PC, in order to ensure its trouble free operation. Various means of determining these settings exist, for example, the Device Manager in Windows 95 or the MSD program in MS-DOS, but these do not always give the complete picture and should be used for indication only. Settings for legacy devices such as ISA cards are determined most accurately by examining the appropriate hardware, or contacting the supplier. PCI device settings can change, but are usually reported by the BIOS at boot time.

The recommended settings layout of the Quad card when the PC only has 1 other serial port, COM1, is shown in Figure 2-1a) (Quad factory default) and also in Table 2-1, on the next page. The recommended configurations of the Quad card when the PC already has 2 other serial ports, COM1 and COM2, installed and use of the card with Digiboard PC/4 defaults is shown in Figure 2-1b) and Figure 2-1c) respectively, and also given in Table 2-1,

below.

If only one PC interrupt line is available several cards may share it; refer to Chapter 6 “**Quad and Lynx Shared Interrupt Mechanisms**” for More Details.

Table 2 -1 AT Quad 4 Port card configuration.

Card Settings	COM1 only	COM1 & COM2	Digiboard PC/4
Port#1	COM2	COM3	Bank
Port#2	COM3	COM4	Bank
Port#3	COM4	Bank	Bank
Port#4	Bank	Bank	Bank
Shared IRQ	3	10	3
Bank address	180-198h	180-1B8h	100-138h
SISR address	3A0h	3A0h	140h
Multi Card	EI + GND	EI + GND	EI + GND
Card ID	0	0	0
Last (CARD ID Dip 4)	ON	ON	ON

The three configurable options are:-

1. Serial Port Setup.

Allocate each serial port its I/O address and interrupt line.

2. Shared Interrupt Setup.

Set the Shared Interrupt Status Register (SISR) I/O address and interrupt line. For more information on this subject refer to Chapter 6 “**Quad and Lynx Shared Interrupt Mechanisms**” and the sections below concerning shared interrupt settings.

3. Multiple Card Setup.

Refer to the sections at the end of Chapter 2 and 3 entitled “**One Card Quad Systems**” and “**One card Lynx Systems**” respectively, and also to the section “**Multiple card systems**” Chapter 6

The Ideal Situation.

If your serial communications packages are configurable for I/O address and interrupt then set all the serial ports in your system so that each serial port has its own separate I/O address, and interrupt not used by any other device in the PC.

Serial Port Configuration.

Serial Port Connectors

The AT Quad 4 Port card possesses four 9 pin serial ports, connected via a 37 pin female port, port pin outs are given in Chapter 7 "**RS232 Port Cabling.**"

Serial Port Setup.

The position of the movable jumper on the address jumper blocks determines the I/O address of the serial ports, configuring the card as either COM1 to COM4 or 100h to 3F8h.

The 4 serial ports are configurable separately or via a common I/O address bank selected via DIPS 1-7 on the BANK ADDRESS 8-way DIP switch, their locations are indicated in figure 2-1.

Individual Serial Port Configuration

The serial ports can be configured to any arrangement of COM 1 to COM 4 (see the section entitled "**Configuring the AT Quad 4 Port RS232**"), figure 2-2, below, shows the address allocation jumper block with default settings.

Figure 2-2. Serial Port Jumper Address Block


<u>Jumper</u>	<u>Port</u>	<u>Address</u>	<u>Normal IRQ Allocation</u>
COM 4  COM 3  COM 2  COM 1  BANK 	COM4	02E8h	IRQ 3 (DEFAULT SETTING FOR SERIAL 3)
COM 4  COM 3  COM 2  COM 1  BANK 	COM3	03E8h	IRQ 3 (DEFAULT SETTING FOR SERIAL 2)
COM 4  COM 3  COM 2  COM 1  BANK 	COM2	02F8h	IRQ 3 (DEFAULT SETTING FOR SERIAL 1)
COM 4  COM 3  COM 2  COM 1  BANK 	COM 1	03F8h	IRQ 4
COM 4  COM 3  COM 2  COM 1  BANK 	BANK	As BANK	IRQ 3 (DEFAULT SETTING FOR SERIAL 4 +)

If no port is selected on the jumper block, i.e. a jumper is not placed on any port setting then that port is disabled, and it is not available for use

Serial Port Bank Address Configuration

This 32-byte bank, shown below in figure 2-3 with default settings, containing the 4 serial ports, may be any address on an 8-byte boundary in the range 0100-03C0 Hex. E.g. 0100h, 0108h, 0110h, 0200h, 0240h, 0280h, 02C0h, 03C0h etc. DIP 8 is part of the SISR register address select.

Figure 2-3. Serial Port Bank Address Allocation



Within this 32-byte bank, port 1 - port 4 are decoded consecutively. E.g. Port 1 is at the bank address, port 2 at bank+8, port 3 at bank+16, and port 4 at bank+24. For added flexibility the four ports can be individually set, using jumpers, to be either at their own bank I/O address or at any of COM1, 2, 3 or COM4.

In all, each of serial ports 1-4 may be set to 1 of 96 addresses. The default bank I/O address is 180hex.

If COM1 - COM4 are already present in the PC then the suggested alternate I/O addresses are Port 1 at 0180 hex, Port 2 at 0188 hex, Port 3 at 0190 hex and Port 4 at 198 hex all using the shared interrupt on IRQ7, IRQ10 or IRQ11.

The best addresses for the serial ports are in the range 0100-01EF hex, which is rarely used and 0200-023F hex & 0280-02BF hex which are usually unused.

I/O addresses to avoid are given in Figure 2-5.

Figure 2-4. Valid Quad Port Base Addresses.

DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	SWITCH	P#1	P#2	P#3	P#4
On	Off	On	On	On	Off	Off		-	-	-	100
On	Off	On	On	On	Off	On		-	-	100	108
On	Off	On	On	On	On	Off		-	100	108	110
On	Off	On	On	On	On	On		100	108	110	118
On	Off	On	On	Off	Off	Off		108	110	118	120
On	Off	On	On	Off	Off	On		110	118	120	128
On	Off	On	On	Off	On	Off		118	120	128	130
On	Off	On	On	Off	On	On		120	128	130	138
On	Off	On	Off	On	Off	Off		128	130	138	140
On	Off	On	Off	On	Off	On		130	138	140	148
On	Off	On	Off	On	On	Off		138	140	148	150
On	Off	On	Off	On	On	On		140	148	150	158
On	Off	On	Off	Off	Off	Off		148	150	158	160
On	Off	On	Off	Off	Off	On		150	158	160	168
On	Off	On	Off	Off	On	Off		158	160	168	170
On	Off	On	Off	Off	On	On		160	168	170	178
On	Off	Off	On	On	Off	Off		168	170	178	180
On	Off	Off	On	On	Off	On		170	178	180	188
On	Off	Off	On	On	On	Off		178	180	188	190
On	Off	Off	On	On	On	On		180	188	190	198
On	Off	Off	On	Off	Off	Off		188	190	198	1A0
On	Off	Off	On	Off	Off	On		190	198	1A0	1A8
On	Off	Off	On	Off	On	Off		198	1A0	1A8	1B0
On	Off	Off	On	Off	On	On		1A0	1A8	1B0	1B8

DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	SWITCH	P#1	P#2	P#3	P#4
On	Off	Off	Off	On	Off	Off		1A8	1B0	1B8	1C0
On	Off	Off	Off	On	Off	On		1B0	1B8	1C0	1C8
On	Off	Off	Off	On	On	Off		1B8	1C0	1C8	1D0
On	Off	Off	Off	On	On	On		1C0	1C8	1D0	1D8
On	Off	Off	Off	Off	Off	Off		1C8	1D0	1D8	1E0
On	Off	Off	Off	Off	Off	On		1D0	1D8	1E0	1E8
On	Off	Off	Off	Off	On	Off		1D8	1E0	1E8	1F0
On	Off	Off	Off	Off	On	On		1E0	1E8	1F0	1F8
Off	On	On	On	On	Off	Off		1E8	1F0	1F8	200
Off	On	On	On	On	Off	On		1F0	1F8	200	208
Off	On	On	On	On	On	Off		1F8	200	208	210
Off	On	On	On	On	On	On		200	208	210	218
Off	On	On	On	Off	Off	Off		208	210	218	220
Off	On	On	On	Off	Off	On		210	218	220	228
Off	On	On	On	Off	On	Off		218	220	228	230
Off	On	On	On	Off	On	On		220	228	230	238
Off	On	On	Off	On	Off	Off		228	230	238	240
Off	On	On	Off	On	Off	On		230	238	240	248
Off	On	On	Off	On	On	Off		238	240	248	250
Off	On	On	Off	On	On	On		240	248	250	258
Off	On	On	Off	Off	Off	Off		248	250	258	260
Off	On	On	Off	Off	Off	On		250	258	260	268
Off	On	On	Off	Off	On	Off		258	260	268	270
Off	On	On	Off	Off	On	On		260	268	270	278

DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	SWITCH	P#1	P#2	P#3	P#4
Off	On	Off	On	On	Off	Off		268	270	278	280
Off	On	Off	On	On	Off	On		270	278	280	288
Off	On	Off	On	On	On	Off		278	280	288	290
Off	On	Off	On	On	On	On		280	288	290	298
Off	On	Off	On	Off	Off	Off		288	290	298	2A0
Off	On	Off	On	Off	Off	On		290	298	2A0	2A8
Off	On	Off	On	Off	On	Off		298	2A0	2A8	2B0
Off	On	Off	On	Off	On	On		2A0	2A8	2B0	2B8
Off	On	Off	Off	On	Off	Off		2A8	2B0	2B8	2C0
Off	On	Off	Off	On	Off	On		2B0	2B8	2C0	2C8
Off	On	Off	Off	On	On	Off		2B8	2C0	2C8	2D0
Off	On	Off	Off	On	On	On		2C0	2C8	2D0	2D8
Off	On	Off	Off	Off	Off	Off		2C8	2D0	2D8	2E0
Off	On	Off	Off	Off	Off	On		2D0	2D8	2E0	2E8
Off	On	Off	Off	Off	On	Off		2D8	2E0	2E8	2F0
Off	On	Off	Off	Off	On	On		2E0	2E8	2F0	2F8
Off	Off	On	On	On	Off	Off		2E8	2F0	2F8	300
Off	Off	On	On	On	Off	On		2F0	2F8	300	308
Off	Off	On	On	On	On	Off		2F8	300	308	310
Off	Off	On	On	On	On	On		300	308	310	318
Off	Off	On	On	Off	Off	Off		308	310	318	320
Off	Off	On	On	Off	Off	On		310	318	320	328
Off	Off	On	On	Off	On	Off		318	320	328	330
Off	Off	On	On	Off	On	On		320	328	330	338

DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	SWITCH	P#1	P#2	P#3	P#4
Off	Off	On	Off	On	Off	Off		328	330	338	340
Off	Off	On	Off	On	Off	On		330	338	340	348
Off	Off	On	Off	On	On	Off		338	340	348	350
Off	Off	On	Off	On	On	On		340	348	350	358
Off	Off	On	Off	Off	Off	Off		348	350	358	360
Off	Off	On	Off	Off	Off	On		350	358	360	368
Off	Off	On	Off	Off	On	Off		358	360	368	370
Off	Off	On	Off	Off	On	On		360	368	370	378
Off	Off	Off	On	On	Off	Off		368	370	378	380
Off	Off	Off	On	On	Off	On		370	378	380	388
Off	Off	Off	On	On	On	Off		378	380	388	390
Off	Off	Off	On	On	On	On		380	388	390	398
Off	Off	Off	On	Off	Off	Off		388	390	398	3A0
Off	Off	Off	On	Off	Off	On		390	398	3A0	3A8
Off	Off	Off	On	Off	On	Off		398	3A0	3A8	3B0
Off	Off	Off	On	Off	On	On		3A0	3A8	3E0	3E8
Off	Off	Off	Off	On	Off	Off		3A8	3B0	3B8	3C0
Off	Off	Off	Off	On	Off	On		3B0	3B8	3C0	3C8
Off	Off	Off	Off	On	On	Off		3B8	3C0	3C8	3D0
Off	Off	Off	Off	On	On	On		3C0	3C8	3D0	3D8
Off		3C8	3D0	3D8	3E0						
Off	Off	Off	Off	Off	Off	On		3D0	3D8	3E0	3E8
Off	Off	Off	Off	Off	On	Off		3D8	3E0	3E8	3F0
Off	Off	Off	Off	Off	On	On		3E0	3E8	3F0	3F8

Figure 2-5. I/O Addresses To Avoid.

I/O Address	Normal Use
0102H	VGA Graphics Option Bit
01F0H - 01F7H	IDE Hard Disk
0201H - 0201H	Game Control Adapter
0278H - 027FH	Second Printer Port Adapter
02E1H	*** PC ELITE IEEE Board.
02F8H - 02FFH	*** Second Serial Port Adapter
0300H - 0303H	*** PC IEEE Board
0308H - 030FH	*** PC DIO48 Board
0310H - 031FH	*** PC Timer-DIO Board
0320H - 032FH	PC Hard Disk, Free on AT/386/486
0340H - 0360H	*** PC DIO192 Board
0360H - 036FH	PC Network
0378H - 037FH	*** Printer Port Adapter
0380H - 038CH	S.D.L.C. Communications
03A0H - 03A9H	Primary Binary Sync Comms
03B0H - 03BFH	Monochrome Display and Printer Card
03C0H - 03CFH	VGA & EGA cards
03D0H - 03DFH	VGA cards
03F8H - 03FFH	*** Serial Port Adapter

*** These cards available from your Dealer.

If any of these adapter cards are installed in the PC DO NOT set the any of Quad Serial ports to reside in the same address range. Among the I/O addresses that are likely to be good for the PC are shown in Figure 2-5, above. However, it some other adapter that may be installed in your PC cannot guarantee.

Serial Port IRQ Interrupt Jumper Selection.

The position of the movable jumper on the interrupt jumper block, located in the bottom left hand corner of the card, determines the IRQ vector of the serial ports, configuring the card as IRQ2 - IRQ7, IRQ10 to IRQ12, or IRQ14 to IRQ15.

Most users will require that the IRQ be set to correspond to the serial port address selection. In general, if the serial port address has been set to the standard COM1 or COM2 addresses, i.e. 03F8 and 02F8 Hex then use IRQ 4 and IRQ3 respectively. For non standard serial port addresses, or for software that is not interrupt driven leave the IRQ jumper set to SHARED, see the section below entitled “**Shared Interrupt Setup**” and Chapter 6 “**Quad and Lynx Shared Interrupt Mechanisms**” for further information.


Shared Interrupt Setup.

Shared Interrupt Status Register Address Selection.

The Shared Interrupt Register DIP switch block is located to the right of the bottom centre of the card. The 8 way DIP switch, labelled SISR, in conjunction with DIP 8 on the BANK ADDR DIP switch is used to select the I/O address of the shared interrupt status register. It may be any address on a 2-byte boundary in the range 0100-03FE Hex. E.g. 0100h- 0200h, 0208h, 0210h, 0300h, 03A0 etc.

Depending on what other cards are already installed in the PC the default I/O address may need changing, for further information see the previous section entitled “**Configuring The AT Quad 4 Port RS232**”


Figure 2-7. Default Shared Interrupt Reg Setting.



QUAD Hardware Configuration Guide
Recommended Alternate Setting

AT QUAD AND LYNX RS232


BANK



DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8
X	X	X	X	X	X	X	OFF

NOT USED FOR
SISR SETTINGS

SISR



DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8
OFF	ON						

DEFAULT SETTING 0300h

Figure 2-8. Valid Quad SISR Addresses.

DIP 8	DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8	SISR	
On	Off	On	100							
On	Off	On	On	On	On	Off	On	On	108	
On	Off	On	On	On	Off	On	On	On	110	
On	Off	On	On	On	Off	Off	On	On	118	
On	Off	On	On	Off	On	On	On	On	120	
On	Off	On	On	Off	On	Off	On	On	128	
On	Off	On	On	Off	Off	On	On	On	130	
On	Off	On	On	Off	Off	Off	On	On	138	
On	Off	On	Off	On	On	On	On	On	140	
On	Off	On	Off	On	On	Off	On	On	148	
On	Off	On	Off	On	Off	On	On	On	150	
On	Off	On	Off	On	Off	Off	On	On	158	
On	Off	On	Off	Off	On	On	On	On	160	
On	Off	On	Off	Off	On	Off	On	On	168	
On	Off	On	Off	Off	Off	On	On	On	170	
On	Off	On	Off	Off	Off	Off	On	On	178	
On	Off	Off	On	On	On	On	On	On	180	
On	Off	Off	On	On	On	Off	On	On	188	
On	Off	Off	On	On	Off	On	On	On	190	
On	Off	Off	On	On	Off	Off	On	On	198	
On	Off	Off	On	Off	On	On	On	On	1A0	
On	Off	Off	On	Off	On	Off	On	On	1A8	
On	Off	Off	On	Off	Off	On	On	On	1B0	
On	Off	Off	On	Off	Off	Off	On	On	1B8	

DIP 8	DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8	SISR	
On	Off	Off	Off	On	On	On	On	On	1C0	
On	Off	Off	Off	On	On	Off	On	On	1C8	
On	Off	Off	Off	On	Off	On	On	On	1D0	
On	Off	Off	Off	On	Off	Off	On	On	1D8	
On	Off	Off	Off	Off	On	On	On	On	1E0	
On	Off	Off	Off	Off	On	Off	On	On	1E8	
On	Off	Off	Off	Off	Off	On	On	On	1F0	
On	Off	Off	Off	Off	Off	Off	On	On	1F8	
Off	On	200								
Off	On	On	On	On	On	Off	On	On	208	
Off	On	On	On	On	Off	On	On	On	210	
Off	On	On	On	On	Off	Off	On	On	218	
Off	On	On	On	Off	On	On	On	On	220	
Off	On	On	On	Off	On	Off	On	On	228	
Off	On	On	On	Off	Off	On	On	On	230	
Off	On	On	On	Off	Off	Off	On	On	238	
Off	On	On	Off	On	On	On	On	On	240	
Off	On	On	Off	On	On	Off	On	On	248	
Off	On	On	Off	On	Off	On	On	On	250	
Off	On	On	Off	On	Off	Off	On	On	258	
Off	On	On	Off	Off	On	On	On	On	260	
Off	On	On	Off	Off	On	Off	On	On	268	
Off	On	On	Off	Off	Off	On	On	On	270	
Off	On	On	Off	Off	Off	Off	On	On	278	


DIP 8	DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8	SISR	
Off	On	Off	On	On	On	On	On	On	280	
Off	On	Off	On	On	On	Off	On	On	288	
Off	On	Off	On	On	Off	On	On	On	290	
Off	On	Off	On	On	Off	Off	On	On	298	
Off	On	Off	On	Off	On	On	On	On	2A0	
Off	On	Off	On	Off	On	Off	On	On	2A8	
Off	On	Off	On	Off	Off	On	On	On	2B0	
Off	On	Off	On	Off	Off	Off	On	On	2B8	
Off	On	Off	Off	On	On	On	On	On	2C0	
Off	On	Off	Off	On	On	Off	On	On	2C8	
Off	On	Off	Off	On	Off	On	On	On	2D0	
Off	On	Off	Off	On	Off	Off	On	On	2D8	
Off	On	Off	Off	Off	On	On	On	On	2E0	
Off	On	Off	Off	Off	On	Off	On	On	2E8	
Off	On	Off	Off	Off	Off	On	On	On	2F0	
Off	On	Off	Off	Off	Off	Off	On	On	2F8	
Off	Off	On	300							
Off	Off	On	On	On	On	Off	On	On	308	
Off	Off	On	On	On	Off	On	On	On	310	
Off	Off	On	On	On	Off	Off	On	On	318	
Off	Off	On	On	Off	On	On	On	On	320	
Off	Off	On	On	Off	On	Off	On	On	328	
Off	Off	On	On	Off	Off	On	On	On	330	
Off	Off	On	On	Off	Off	Off	On	On	338	

DIP 8	DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8	SISR	
Off	Off	On	Off	On	On	On	On	On	340	
Off	Off	On	Off	On	On	Off	On	On	348	
Off	Off	On	Off	On	Off	On	On	On	350	
Off	Off	On	Off	On	Off	Off	On	On	358	
Off	Off	On	Off	Off	On	On	On	On	360	
Off	Off	On	Off	Off	On	Off	On	On	368	
Off	Off	On	Off	Off	Off	On	On	On	370	
Off	Off	On	Off	Off	Off	Off	On	On	378	
Off	Off	Off	On	On	On	On	On	On	380	
Off	Off	Off	On	On	On	Off	On	On	388	
Off	Off	Off	On	On	Off	On	On	On	390	
Off	Off	Off	On	On	Off	Off	On	On	398	
Off	Off	Off	On	Off	On	On	On	On	3A0	
Off	Off	Off	On	Off	On	Off	On	On	3A8	
Off	Off	Off	On	Off	Off	On	On	On	3B0	
Off	Off	Off	On	Off	Off	Off	On	On	3B8	
Off	Off	Off	Off	On	On	On	On	On	3C0	
Off	Off	Off	Off	On	On	Off	On	On	3C8	
Off	Off	Off	Off	On	Off	On	On	On	3D0	
Off	Off	Off	Off	On	Off	Off	On	On	3D8	
Off	Off	Off	Off	Off	On	On	On	On	3E0	
Off	Off	Off	Off	Off	On	Off	On	On	3E8	
Off	Off	Off	Off	Off	Off	On	On	On	3F0	
Off	On	On		DO NOT USE						

Shared IRQ Interrupt Jumper Selection.

The location of the SHARED IRQ jumper block is shown in Figure 2-1a). The movable jumper determines which interrupt those serial ports SHARING an interrupt call.

Figure 2-9. Shared IRQ Jumper Block.



NOTE:

IRQ 0 & 8 - Timer & Clock Interrupts, not on expansion bus

IRQ 1 - Keyboard interrupt, not on expansion bus

IRQ 9 - Best left Unexplained, not on expansion bus

IRQ 13 - Maths coprocessor interrupt, not on expansion bus

In order to make use of the shared interrupt settings, the IRQ jumper settings (see the section entitled “**Serial Port IRQ jumper selection**” for further information) for the individual ports are set to the SH position.

Shared Interrupt Mechanism.

The shared interrupt mechanism is a way of using the few available interrupt lines in the PC efficiently. It allows many serial ports to share only one IRQ line. The priority encoding mechanism also allows higher throughput than simply one port per IRQ line. Latching of the first asserted interrupt prevents one port hogging the interrupt line at the expense of other ports. More information about the shared interrupt mechanism and multcard connections can be found in Chapter 6 - “**Shared Interrupt Mechanisms.**”

The Shared Interrupt Register is controlled by a block consisting of 8 dip switches, which is used to select its I/O address, also there is a jumper block to select which PC interrupt line the Shared Interrupt Register is to drive.

One Quad Card Systems.


When only one Quad card is installed in the PC system, the situation for the vast majority of users, then the multi card chaining system must ALWAYS be set in a certain way. The CARD ID switch MUST always be set to 0, i.e. DIPs 1-3 = ON. The LAST setting, DIP 4 on the CARD ID (Figure 2-1 indicates the CARD ID location) should set to ON (LAST CARD = YES). This configuration is shown below in Figure 2-10, “**card ID in 1**

Quad card system”

The two wire chaining cable supplied with the card should not be used, it is only required in multi Quad card systems. Refer to Chapter 6 - “**Shared Interrupt Mechanisms**”, and more specifically the section entitled “Multicard setup” for a more in depth discussion on this subject.


Figure 2-10. CARD ID In 1 Quad Card System.

CARD ID:



Note: On 1 Quad Card System CARD ID = 0
DIP 4 = ON (Last Card)

MULTICARD ID:



CHAPTER 3

AT LYNX 8 PORT RS232 HARDWARE CONFIGURATION.

Introduction.

This chapter explains how to configure the AT LYNX 8 PORT RS232 in a PC compatible, giving details for address and IRQ jumper selection. Detailed instructions are given how to set the address select DIP switches and IRQ jumpers.

This half sized RS232 card will work happily in any PC compatible up to and exceeding Pentium II 300 MHz class machines


AT LYNX 8 PORT RS232 Card Features.

- Eight independent RS232 Serial ports.
- Reliable communications up to 50 feet, 15m, and beyond!
- 100% PC Compatible serial port TI or CMD 16C550, up to 115,200 baud.
- Jumper selectable serial port address, COM1- COM4 and many more!
- Jumper selectable interrupt level IRQ 2-7, 10-12, 14 & 15.
- Shared IRQ settings available for all Ports
- Full modem control TXD, RXD, DSR, DCD, DTR, RTS, CTS and RI signals.
- Fully double buffered for reliable asynchronous operation.
- High-speed integrated circuitry ensures operation with fast PC's e.g. Pentium II 300 MHz WITHOUT extra wait states.
- 16550 FIFO provides 16-byte input and 16-byte output buffer on each port.

The AT LYNX 8 PORT RS232 has the following features:


Baud Rate:	50 Baud to 115200 Baud.
Word Length:	5, 6, 7 or 8 bits.
Parity:	Even, Odd, None, Mark or Space.
Start Bit:	1 start bit always sent.
Stop Bits:	1, (1.5 for 5 bit data word length) or 2.
Clock Input:	1.8432 MHz.

Figure 3-1a). AT LYNX 8 Port RS232 Layout
Com 1 Present:



Card Settings	COM 1 Present
Port #1	COM 2
Port #2	COM 3
Port #3	COM 4
Port #4	Bank
Port #5 - #8	Bank
Shared IRQ	3
Bank Ad.	180-1B8h
SISR Ad.	3A0h
Multi Card	EI + GND
Card ID	0
Last (Card ID dip 4)	ON

Figure 3-1b). AT LYNX 8 Port RS232 Layout
COM 1 and COM 2 Present:



Card Settings	COM 1 & COM 2 Present
Port #1	COM 3
Port #2	COM 4
Port #3	Bank
Port #4	Bank
Port #5 - #8	Bank
Shared IRQ	10
Bank Ad.	180-1B8h
SISR Ad.	3A0h
Multi Card	EI + GND
Card ID	0
Last (Card ID dip 4)	ON

AT LYNX 8 Port RS232 Specifications:

Dimensions: 12 x 18cm; 4.8 x 7.2in.

I/O Connection: 78 way female D connector to 8 serial ports
 Serial Port 1 - 8 all 9 pin connectors

OR

Serial Port 1 - 8 all 25 pin connectors

Table 3 -1 AT Lynx 8 Port card configuration

Card Settings	COM 1 Present	COM1 & COM2 Present	Digiboard PC/8
Port #1	COM 2	COM 3	Bank
Port #2	COM 3	COM 4	Bank
Port #3	COM 4	Bank	Bank
Port #4	Bank	Bank	Bank
Port #5	Bank	Bank	Bank
Port #6	Bank	Bank	Bank
Port #7	Bank	Bank	Bank
Port #8	Bank	Bank	Bank
Shared IRQ	3	10	3
Bank Ad.	180 - 1B8h	180 - 1B8h	100-138h
SISR Ad.	3A0h	3A0h	140h
Multi Card	EI + GND	EI + GND	EI + GND
Card ID	0	0	0
Last (Card ID dip 4)	ON	ON	ON

Configuring The AT LYNX 8 Port RS232

In the state it leaves our factory, the AT LYNX 8 Port RS232 is ready to plug straight into a PC compatible computer. Unless there is GOOD REASON, do not alter its default setting. However, due to the presence of other serial ports in the PC, your card may need configuring to suit your setup.

If your card needs to be reconfigured it is important to

know the settings (particularly IRQ allocations) of any other add on cards / motherboard resources that exist in your PC, in order to ensure its trouble free operation. Various means of determining these settings exist, for example, the Device Manager in Windows 95 or the MSD program in MS-DOS, but these do not always give the complete picture and should be used for indication only. Settings for legacy devices such as ISA cards are determined most accurately by examining the appropriate hardware, or contacting the supplier. PCI device settings can change, but are usually reported by the BIOS at boot time.

The recommended settings layout of the Lynx card when the PC only has 1 other serial port, COM1 installed, is given in Figure 3-1a) (Lynx factory default). The recommended configurations of the Lynx card when the PC already has 2 other serial ports, COM1 and COM2, installed and use of the card with Digiboard PC/8 defaults is given in figures 3-1b) and 3-1c), respectively. See also Table 3-1, above for a summary of these settings.

If only one PC interrupt line is available several cards may share it; refer to Chapter 6 “**Quad and Lynx Shared Interrupt Mechanisms**” for more details.

The three configurable options, that exist for the AT Lynx 8 port are: -

i) **Serial Port Setup.**

Allocate each serial port its I/O address and interrupt line.

ii) **Shared Interrupt Setup.**

Set the Shared Interrupt Status Register (SISR) I/O address and interrupt line. For more information on this subject refer to Chapter 6 “**Quad and Lynx Shared Interrupt Mechanisms**” and the sections below concerning shared interrupt settings.

iii) **Multiple Cards Setup.**

Refer to the sections at the end of Chapter 2 and 3 entitled “**One card Quad Systems**” and “**1 card Lynx Systems**”

respectively, and also to the section “**Multiple card systems**” Chapter 6

The Ideal Situation.

If your serial communications packages are configurable for I/O address and interrupt then set all the serial ports in your system so that each serial port has its own separate I/O address, and interrupt not used by any other device in the PC.

Serial Port Configuration.

The AT Lynx 8 Port card possess eight 9 pin serial ports, connected via a 78 pin female port, RS232 port pin outs are given in Chapter 7 “**RS232 Port Cabling.**”

Serial Port I/O Configuration.

The position of the movable jumper on the address jumper blocks, determines the I/O address of the serial ports, configuring the card as either COM1 to COM4 or 100h to 3F8h. The 4 serial ports are configurable separately or via a common I/O address bank selected via DIPS 1-7 on the BANK ADDRESS 8 way DIP switch; their locations are indicated in Figure 3-1.

Individual Serial Port Configuration

The serial ports can be configured to any arrangement of COM 1 to COM 8 (see the section entitled “**Configuring the AT LYNX 8 Port RS232**”), Figure 3-2, below, shows the address allocation jumper block with default settings.

Figure 3-2. Serial Port Jumper Address Block

<u>Jumper</u>	<u>Port</u>	<u>Address</u>	<u>Normal IRQ Allocation</u>
P8ON  P7ON  P6ON  P5ON 	COM8	As Bank (1B8h default)	IRQ 3 (DEFAULT)
P8ON  P7ON  P6ON  P5ON 	COM7	As Bank (1B0h default)	IRQ 3 (DEFAULT)
P8ON  P7ON  P6ON  P5ON 	COM6	As Bank (1A8h default)	IRQ 3 (DEFAULT)
P8ON  P7ON  P6ON  P5ON 	COM5	As Bank (1A0h default)	IRQ 3 (DEFAULT)
COM 4  COM 3  COM 2  COM 1  BANK 	COM4	02E8h	IRQ 3 (DEFAULT SETTING FOR SERIAL 3)
COM 4  COM 3  COM 2  COM 1  BANK 	COM3	03E8h	IRQ 3 (DEFAULT SETTING FOR SERIAL 2)
COM 4  COM 3  COM 2  COM 1  BANK 	COM2	02F8h	IRQ 3 (DEFAULT SETTING FOR SERIAL 1)
COM 4  COM 3  COM 2  COM 1  BANK 	COM 1	03F8h	IRQ 4
COM 4  COM 3  COM 2  COM 1  BANK 	BANK	As BANK	IRQ 3 (DEFAULT SETTING FOR SERIAL 4 +)

Figure 3-4. Valid Lynx Port Base Addresses.

DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	SWITCH	P#1	P#2	P#3	P#4	P#5	P#6	P#7	P#8
On	Off	On	On	Off	Off	Off		-	-	-	-	-	-	-	100
On	Off	On	On	Off	Off	On		-	-	-	-	-	-	100	108
On	Off	On	On	Off	On	Off		-	-	-	-	-	100	108	110
On	Off	On	On	Off	On	On		-	-	-	-	100	108	110	118
On	Off	On	On	On	Off	Off		-	-	-	100	108	110	118	120
On	Off	On	On	On	Off	On		-	-	100	108	110	118	120	128
On	Off	On	On	On	On	Off		-	100	108	110	118	120	128	130
On	Off	On	On	On	On	On		100	108	110	118	120	128	130	138
On	Off	On	Off	Off	Off	Off		108	110	118	120	128	130	138	140
On	Off	On	Off	Off	Off	On		110	118	120	128	130	138	140	148
On	Off	On	Off	Off	On	Off		118	120	128	130	138	140	148	150
On	Off	On	Off	Off	On	On		120	128	130	138	140	148	150	158
On	Off	On	Off	On	Off	Off		128	130	138	140	148	150	158	160
On	Off	On	Off	On	Off	On		130	138	140	148	150	158	160	168
On	Off	On	Off	On	On	Off		138	140	148	150	158	160	168	170
On	Off	On	Off	On	On	On		140	148	150	158	160	168	170	178
On	Off	Off	On	Off	Off	Off		148	150	158	160	168	170	178	180
On	Off	Off	On	Off	Off	On		150	158	160	168	170	178	180	188
On	Off	Off	On	Off	On	Off		158	160	168	170	178	180	188	190
On	Off	Off	On	Off	On	On		160	168	170	178	180	188	190	198
On	Off	Off	On	On	Off	Off		168	170	178	180	188	190	198	1A0
On	Off	Off	On	On	Off	On		170	178	180	188	190	198	1A0	1A8
On	Off	Off	On	On	On	Off		178	180	188	190	198	1A0	1A8	1B0
On	Off	Off	On	On	On	On		180	188	190	198	1A0	1A8	1B0	1B8

DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	SWITCH	P#1	P#2	P#3	P#4	P#5	P#6	P#7	P#8
On	Off	Off	Off	Off	Off	Off		188	190	198	1A0	1A8	1B0	1B8	1C0
On	Off	Off	Off	Off	Off	On		190	198	1A0	1A8	1B0	1B8	1C0	1C8
On	Off	Off	Off	Off	On	Off		198	1A0	1A8	1B0	1B8	1C0	1C8	1D0
On	Off	Off	Off	Off	On	On		1A0	1A8	1B0	1B8	1C0	1C8	1D0	1D8
On	Off	Off	Off	On	Off	Off		1A8	1B0	1B8	1C0	1C8	1D0	1D8	1E0
On	Off	Off	Off	On	Off	On		1B0	1B8	1C0	1C8	1D0	1D8	1E0	1E8
On	Off	Off	Off	On	On	Off		1B8	1C0	1C8	1D0	1D8	1E0	1E8	1F0
On	Off	Off	Off	On	On	On		1C0	1C8	1D0	1D8	1E0	1E8	1F0	1F8
Off	On	On	On	Off	Off	Off		1C8	1D0	1D8	1E0	1E8	1F0	1F8	200
Off	On	On	On	Off	Off	On		1D0	1D8	1E0	1E8	1F0	1F8	200	208
Off	On	On	On	Off	On	Off		1D8	1E0	1E8	1F0	1F8	200	208	210
Off	On	On	On	Off	On	On		1E0	1E8	1F0	1F8	200	208	210	218
Off	On	On	On	On	Off	Off		1E8	1F0	1F8	200	208	210	218	220
Off	On	On	On	On	Off	On		1F0	1F8	200	208	210	218	220	228
Off	On	On	On	On	On	Off		1F8	200	208	210	218	220	228	230
Off	On	On	On	On	On	On		200	208	210	218	220	228	230	238
Off	On	On	Off	Off	Off	Off		208	210	218	220	228	230	238	240
Off	On	On	Off	Off	Off	On		210	218	220	228	230	238	240	248
Off	On	On	Off	Off	On	Off		218	220	228	230	238	240	248	250
Off	On	On	Off	Off	On	On		220	228	230	238	240	248	250	258
Off	On	On	Off	On	Off	Off		228	230	238	240	248	250	258	260
Off	On	On	Off	On	Off	On		230	238	240	248	250	258	260	268
Off	On	On	Off	On	On	Off		238	240	248	250	258	260	268	270
Off	On	On	Off	On	On	On		240	248	250	258	260	268	270	278

LYNX Hardware Configuration Guide

AT QUAD AND LYNX RS232

DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	SWITCH	P#1	P#2	P#3	P#4	P#5	P#6	P#7	P#8
Off	On	Off	On	Off	Off	Off		248	250	258	260	268	270	278	280
Off	On	Off	On	Off	Off	On		250	258	260	268	270	278	280	288
Off	On	Off	On	Off	On	Off		258	260	268	270	278	280	288	290
Off	On	Off	On	Off	On	On		260	268	270	278	280	288	290	298
Off	On	Off	On	On	Off	Off		268	270	278	280	288	290	298	2A0
Off	On	Off	On	On	Off	On		270	278	280	288	290	298	2A0	2A8
Off	On	Off	On	On	On	Off		278	280	288	290	298	2A0	2A8	2B0
Off	On	Off	On	On	On	On		280	288	290	298	2A0	2A8	2B0	2B8
Off	On	Off	Off	Off	Off	Off		288	290	298	2A0	2A8	2B0	2B8	2C0
Off	On	Off	Off	Off	Off	On		290	298	2A0	2A8	2B0	2B8	2C0	2C8
Off	On	Off	Off	Off	On	Off		298	2A0	2A8	2B0	2B8	2C0	2C8	2D0
Off	On	Off	Off	Off	On	On		2A0	2A8	2B0	2B8	2C0	2C8	2D0	2D8
Off	On	Off	Off	On	Off	Off		2A8	2B0	2B8	2C0	2C8	2D0	2D8	2E0
Off	On	Off	Off	On	Off	On		2B0	2B8	2C0	2C8	2D0	2D8	2E0	2E8
Off	On	Off	Off	On	On	Off		2B8	2C0	2C8	2D0	2D8	2E0	2E8	2F0
Off	On	Off	Off	On	On	On		2C0	2C8	2D0	2D8	2E0	2E8	2F0	2F8
Off	Off	On	On	Off	Off	Off		2C8	2D0	2D8	2E0	2E8	2F0	2F8	300
Off	Off	On	On	Off	Off	On		2D0	2D8	2E0	2E8	2F0	2F8	300	308
Off	Off	On	On	Off	On	Off		2D8	2E0	2E8	2F0	2F8	300	308	310
Off	Off	On	On	Off	On	On		2E0	2E8	2F0	2F8	300	308	310	318
Off	Off	On	On	On	Off	Off		2E8	2F0	2F8	300	308	310	318	320
Off	Off	On	On	On	Off	On		2F0	2F8	300	308	310	318	320	328
Off	Off	On	On	On	On	Off		2F8	300	308	310	318	320	328	330
Off	Off	On	On	On	On	On		300	308	310	318	320	328	330	338

DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	SWITCH	P#1	P#2	P#3	P#4	P#5	P#6	P#7	P#8
Off	Off	On	Off	Off	Off	Off		308	310	318	320	328	330	338	340
Off	Off	On	Off	Off	Off	On		310	318	320	328	330	338	340	348
Off	Off	On	Off	Off	On	Off		318	320	328	330	338	340	348	350
Off	Off	On	Off	Off	On	On		320	328	330	338	340	348	350	358
Off	Off	On	Off	On	Off	Off		328	330	338	340	348	350	358	360
Off	Off	On	Off	On	Off	On		330	338	340	348	350	358	360	368
Off	Off	On	Off	On	On	Off		338	340	348	350	358	360	368	370
Off	Off	On	Off	On	On	On		340	348	350	358	360	368	370	378
Off	Off	Off	On	Off	Off	Off		348	350	358	360	368	370	378	380
Off	Off	Off	On	Off	Off	On		350	358	360	368	370	378	380	388
Off	Off	Off	On	Off	On	Off		358	360	368	370	378	380	388	390
Off	Off	Off	On	Off	On	On		360	368	370	378	380	388	390	398
Off	Off	Off	On	On	Off	Off		368	370	378	380	388	390	398	3A0
Off	Off	Off	On	On	Off	On		370	378	380	388	390	398	3A0	3A8
Off	Off	Off	On	On	On	Off		378	380	388	390	398	3A0	3A8	3B0
Off	Off	Off	On	On	On	On		380	388	390	398	3A0	3A8	3B0	3B8
Off		388	390	398	3A0	3A8	3B0	3B8	3C0						
Off	Off	Off	Off	Off	Off	On		390	398	3A0	3A8	3B0	3B8	3C0	3C8
Off	Off	Off	Off	Off	On	Off		398	3A0	3A8	3B0	3B8	3C0	3C8	3D0
Off	Off	Off	Off	Off	On	On		3A0	3A8	3B0	3B8	3C0	3C8	3D0	3D8
Off	Off	Off	Off	On	Off	Off		3A8	3B0	3B8	3C0	3C8	3D0	3D8	3E0
Off	Off	Off	Off	On	Off	On		3B0	3B8	3C0	3C8	3D0	3D8	3E0	3E8
Off	Off	Off	Off	On	On	Off		3B8	3C0	3C8	3D0	3D8	3E0	3E8	3F0
Off	Off	Off	Off	On	On	On		3C0	3C8	3D0	3D8	3E0	3E8	3F0	3F8

Figure 3-5. I/O Addresses To Avoid.

I/O Address	Normal Use
0102H	VGA Graphics Option Bit
01F0H - 01F7H	IDE Hard Disk
0201H - 0201H	Game Control Adapter
0278H - 027FH	Second Printer Port Adapter
02E1H	*** PC ELITE IEEE Board.
02F8H - 02FFH	*** Second Serial Port Adapter
0300H - 0303H	*** PC IEEE Board
0308H - 030FH	*** PC DIO48 Board
0310H - 031FH	*** PC Timer-DIO Board
0320H - 032FH	PC Hard Disk, Free on AT/386/486
0340H - 0360H	*** PC DIO192 Board
0360H - 036FH	PC Network
0378H - 037FH	*** Printer Port Adapter
0380H - 038CH	S.D.L.C. Communications
03A0H - 03A9H	Primary Binary Sync Comms
03B0H - 03BFH	Monochrome Display and Printer Card
03C0H - 03CFH	VGA & EGA cards
03D0H - 03DFH	VGA cards
03F8H - 03FFH	*** Serial Port Adapter

*** These cards available from your Dealer.


If any of these adapter cards are installed in the PC DO NOT set the any of Lynx Serial ports to reside in the same address range. Among the I/O addresses that are likely to be good for the PC are shown in Figure 3-4, above. However, we cannot guarantee that they are not already in use by some other adapter that may be installed in your PC.

Serial Port IRQ Interrupt Jumper Selection.

The position of the movable jumper on the interrupt jumper block, located in the bottom left hand corner of the card, determines the IRQ vector of the serial ports, configuring the card as IRQ2 - IRQ7, IRQ10 to IRQ12, or IRQ14 to IRQ15.

Most users will require that the IRQ is set to correspond to the serial port address selection. In general, if the serial port address has been set to the standard COM1 or COM2 addresses, ie 03F8 and 02F8 Hex then use IRQ 4 and IRQ3 respectively. For non standard serial port addresses, or for software that is not interrupt driven leave the IRQ jumper set to SHARED, see the section below entitled “**Shared Interrupt Setup**” and Chapter 6 “**Quad and Lynx Shared Interrupt Mechanisms**” for further information.

Figure 3-6. Port IRQ Jumper Block.



NOTE:

- IRQ 0 & 8 - Timer & Clock Interrupts, not on expansion bus
- IRQ 1 - Keyboard interrupt, not on expansion bus
- IRQ 9 - Best left Unexplained, not on expansion bus
- IRQ 13 - Maths coprocessor interrupt, not on expansion bus


Shared Interrupt Setup.

Shared Interrupt Status Register Address Selection.

The Shared Interrupt Register DIP switch block is located to the right of the bottom centre of the card. The 8 way DIP switch, labelled SISR, in conjunction with DIP 8 on the BANK ADDR DIP switch is used to select the I/O address of the shared interrupt status register. It may be any address on an 2 byte boundary in the range 0100-03FE Hex. E.g. 0100h- 0200h, 0208h, 0210h, 0300h, 03A0 etc.

Depending on what other cards are already installed in the PC the default I/O address may need changing, for further information see the previous section entitled “**Configuring The AT LYNX 8 Port RS232**”


Figure 3-7. Default Shared Interrupt Reg Setting.



LYNX Hardware Configuration Guide
Recommended Alternate Setting

AT QUAD AND LYNX RS232


BANK



DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8
X	X	X	X	X	X	X	OFF

NOT USED FOR
SISR SETTINGS

SISR



DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8
OFF	ON						

DEFAULT SETTING 0300h

Figure 3-8. Valid Lynx SISR Addresses.

DIP 8	DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8	SISR	
On	Off	On	100							
On	Off	On	On	On	On	Off	On	On	108	
On	Off	On	On	On	Off	On	On	On	110	
On	Off	On	On	On	Off	Off	On	On	118	
On	Off	On	On	Off	On	On	On	On	120	
On	Off	On	On	Off	On	Off	On	On	128	
On	Off	On	On	Off	Off	On	On	On	130	
On	Off	On	On	Off	Off	Off	On	On	138	
On	Off	On	Off	On	On	On	On	On	140	
On	Off	On	Off	On	On	Off	On	On	148	
On	Off	On	Off	On	Off	On	On	On	150	
On	Off	On	Off	On	Off	Off	On	On	158	
On	Off	On	Off	Off	On	On	On	On	160	
On	Off	On	Off	Off	On	Off	On	On	168	
On	Off	On	Off	Off	Off	On	On	On	170	
On	Off	On	Off	Off	Off	Off	On	On	178	
On	Off	Off	On	On	On	On	On	On	180	
On	Off	Off	On	On	On	Off	On	On	188	
On	Off	Off	On	On	Off	On	On	On	190	
On	Off	Off	On	On	Off	Off	On	On	198	
On	Off	Off	On	Off	On	On	On	On	1A0	
On	Off	Off	On	Off	On	Off	On	On	1A8	
On	Off	Off	On	Off	Off	On	On	On	1B0	
On	Off	Off	On	Off	Off	Off	On	On	1B8	

DIP 8	DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8	SISR	
On	Off	Off	Off	On	On	On	On	On	1C0	
On	Off	Off	Off	On	On	Off	On	On	1C8	
On	Off	Off	Off	On	Off	On	On	On	1D0	
On	Off	Off	Off	On	Off	Off	On	On	1D8	
On	Off	Off	Off	Off	On	On	On	On	1E0	
On	Off	Off	Off	Off	On	Off	On	On	1E8	
On	Off	Off	Off	Off	Off	On	On	On	1F0	
On	Off	Off	Off	Off	Off	Off	On	On	1F8	
Off	On	200								
Off	On	On	On	On	On	Off	On	On	208	
Off	On	On	On	On	Off	On	On	On	210	
Off	On	On	On	On	Off	Off	On	On	218	
Off	On	On	On	Off	On	On	On	On	220	
Off	On	On	On	Off	On	Off	On	On	228	
Off	On	On	On	Off	Off	On	On	On	230	
Off	On	On	On	Off	Off	Off	On	On	238	
Off	On	On	Off	On	On	On	On	On	240	
Off	On	On	Off	On	On	Off	On	On	248	
Off	On	On	Off	On	Off	On	On	On	250	
Off	On	On	Off	On	Off	Off	On	On	258	
Off	On	On	Off	Off	On	On	On	On	260	
Off	On	On	Off	Off	On	Off	On	On	268	
Off	On	On	Off	Off	Off	On	On	On	270	
Off	On	On	Off	Off	Off	Off	On	On	278	


DIP 8	DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8	SISR	
Off	On	Off	On	On	On	On	On	On	280	
Off	On	Off	On	On	On	Off	On	On	288	
Off	On	Off	On	On	Off	On	On	On	290	
Off	On	Off	On	On	Off	Off	On	On	298	
Off	On	Off	On	Off	On	On	On	On	2A0	
Off	On	Off	On	Off	On	Off	On	On	2A8	
Off	On	Off	On	Off	Off	On	On	On	2B0	
Off	On	Off	On	Off	Off	Off	On	On	2B8	
Off	On	Off	Off	On	On	On	On	On	2C0	
Off	On	Off	Off	On	On	Off	On	On	2C8	
Off	On	Off	Off	On	Off	On	On	On	2D0	
Off	On	Off	Off	On	Off	Off	On	On	2D8	
Off	On	Off	Off	Off	On	On	On	On	2E0	
Off	On	Off	Off	Off	On	Off	On	On	2E8	
Off	On	Off	Off	Off	Off	On	On	On	2F0	
Off	On	Off	Off	Off	Off	Off	On	On	2F8	
Off	Off	On	300							
Off	Off	On	On	On	On	Off	On	On	308	
Off	Off	On	On	On	Off	On	On	On	310	
Off	Off	On	On	On	Off	Off	On	On	318	
Off	Off	On	On	Off	On	On	On	On	320	
Off	Off	On	On	Off	On	Off	On	On	328	
Off	Off	On	On	Off	Off	On	On	On	330	
Off	Off	On	On	Off	Off	Off	On	On	338	

DIP 8	DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8	SISR	
Off	Off	On	Off	On	On	On	On	On	340	
Off	Off	On	Off	On	On	Off	On	On	348	
Off	Off	On	Off	On	Off	On	On	On	350	
Off	Off	On	Off	On	Off	Off	On	On	358	
Off	Off	On	Off	Off	On	On	On	On	360	
Off	Off	On	Off	Off	On	Off	On	On	368	
Off	Off	On	Off	Off	Off	On	On	On	370	
Off	Off	On	Off	Off	Off	Off	On	On	378	
Off	Off	Off	On	On	On	On	On	On	380	
Off	Off	Off	On	On	On	Off	On	On	388	
Off	Off	Off	On	On	Off	On	On	On	390	
Off	Off	Off	On	On	Off	Off	On	On	398	
Off	Off	Off	On	Off	On	On	On	On	3A0	
Off	Off	Off	On	Off	On	Off	On	On	3A8	
Off	Off	Off	On	Off	Off	On	On	On	3B0	
Off	Off	Off	On	Off	Off	Off	On	On	3B8	
Off	Off	Off	Off	On	On	On	On	On	3C0	
Off	Off	Off	Off	On	On	Off	On	On	3C8	
Off	Off	Off	Off	On	Off	On	On	On	3D0	
Off	Off	Off	Off	On	Off	Off	On	On	3D8	
Off	Off	Off	Off	Off	On	On	On	On	3E0	
Off	Off	Off	Off	Off	On	Off	On	On	3E8	
Off	Off	Off	Off	Off	Off	On	On	On	3F0	
Off	On	On		DO NOT USE						

Shared IRQ Interrupt Jumper Selection.

The SHARED IRQ jumper block is located immediately to the left of the bottom centre of the card. The movable jumper determines which interrupt is called by those serial ports SHARING an interrupt.

Figure 3-9. Shared IRQ Jumper Block.



NOTE:

- IRQ 0 & 8 - Timer & Clock Interrupts, not on expansion bus
- IRQ 1 - Keyboard interrupt, not on expansion bus
- IRQ 9 - Best left Unexplained, not on expansion bus
- IRQ 13 - Maths coprocessor interrupt, not on expansion bus

In order to make use of the shared interrupt settings, the IRQ jumper settings (see the section entitled “**Serial Port IRQ jumper selection**” for further information) for the individual ports are set to the SH position.

Shared Interrupt Mechanism.

The shared interrupt mechanism is a way of using the few available interrupt lines in the PC efficiently. It allows many serial ports to share only one IRQ line. The priority encoding mechanism also allows higher throughput than simply one port per IRQ line. Latching of the first asserted interrupt prevents one port hogging the interrupt line at the expense of other ports. More information about the shared interrupt mechanism and multi card connections can be found in Chapter 6 - “**Shared Interrupt Mechanisms.**”

The Shared Interrupt Register is a block consisting of 8 dip switches, to select its I/O address also there is a jumper block to select which PC interrupt line the Shared Interrupt Register is to drive.

One Lynx Card Systems.


When only one Lynx card is installed in the PC system, the situation for the vast majority of users, then the multi card chaining system must ALWAYS be set in a certain way. The CARD ID switch MUST always be set to 0, i.e. all DIPs ON. The LAST setting, DIP 4 on the CARD ID (Figure 3-1 indicates the CARD ID location) should be set to ON (LAST CARD = YES). This configuration is shown below in Figure 3-10, “**card ID in 1**

Lynx card system”

The two wire chaining cable supplied with the card should not be used, it is only required in multi Lynx card systems. Refer to Chapter 6 - “**Shared Interrupt Mechanisms**”, and more specifically the section entitled “Multicard setup” for a more in depth discussion on this subject.

Figure 2-10. CARD ID In 1 Lynx Card System.

CARD ID:



Note: On 1 Lynx Card System CARD ID = 0
DIP 4 = ON (Last Card)

MULTICARD ID:

<div style="border: 1px solid black; width: 15px; height: 15px; background-color: #808080; margin-bottom: 2px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px; background-color: #808080; margin-bottom: 2px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px; background-color: white; margin-bottom: 2px;"></div>	EI (External Interrupt Input) GND (Ground)	{ SHORT WITH JUMPER { SHORT WITH JUMPER
<div style="border: 1px solid black; width: 15px; height: 15px; background-color: #808080; margin-bottom: 2px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px; background-color: #808080;"></div>	EO (External Interrupt Output) GND (Ground)	{ LEAVE UNCONNECTED { LEAVE UNCONNECTED

CHAPTER 4

INSTALLING THE PC SERIAL CARD IN THE COMPUTER.

Serial Card Installation.

Once the card has been correctly configured then it can be installed in the PC. It is best to make a note of the serial port I/O address selection and IRQ jumper settings for later use.

In general, the card should be configured, then installed and if your BIOS only detects 2 serial ports, run or add to the AUTOEXEC.BAT file, the ADDRCOM3/4 programs, see Chapter 5 - “**AT Quad 4 Port and AT Lynx 8 Port Software Configuration**”.


Finally cables should be attached and communication with the serial peripheral devices should be established.

Provided that the RS232 installation is attacked in this orderly manner, everything should work first time. If it does not then check the software selectable communications parameters, Baud rate, Parity, stop bits first, and that the communications program is attempting to access the serial port installed. If this fails to solve the problem check the cable connections. Finally check that the card is indeed configured as you believed!


NOTE: Always turn the computer OFF before installing or removing any interface board!!!

After having made sure that the I/O address and jumpers are correctly set, now is the time to insert the PC Serial card into the I/O connector slots in the computer.


STEP 1: Before the PC card can be installed the power to the PC **MUST** be switched **OFF!** Also, to ensure further safety unplug the power lead from the PC.

Figure 4-1. Remove Cover Mounting Screws.


STEP 2: Then using a screw driver, remove the cover mounting screws on the back panel of the PC system unit.

Figure 4-2. Removing The PC Cover.

STEP 3: Next, remove the PC's cover by sliding it forward and up. It usually helps to disconnect the keyboard from the PC since it tends to get in the way when the case is removed.

Figure 4-3. Removing Blanking Cover

STEP 4: Choose an empty expansion slot. The PC Serial card will fit either a full length or a short slot, a 8 bit PC type slot or a 16 bit AT type slot. In general it is wise to leave the larger slots free for those boards that insist on greater room. Remove the blanking cover protecting the slot on the PC back panel. **KEEP** the blanking cover screw safely for later.

Figure 4-4. Inserting The PC Serial Card.

STEP 5: Now insert the PC Serial card in the slot. Be careful to ensure that the gold plated PCB fingers fits neatly into the I/O

expansion connector. Press down firmly but evenly on the top of the PC Serial card.

STEP 6: The card D connector should fit neatly through the slot's aperture to the outside world. NB. Use the screw kept back from the blanking cover to screw the PC Serial retaining bracket into the PC back panel housing. It is recommended that a careful inspection of the area surrounding the card is made to ensure that any potentially harmful bits of metal etc. are not present.

STEP 7: Now replace the system units cover by carefully sliding it down and back over the system unit. Replace the cover mounting screws.

STEP 8: After attaching all the monitor and keyboard cables, power up the PC. Do not forget the mains power cable! The PC should power on in the normal way.

Problems!

If the system fails to power up normally check the following.:

- i.) Ensure that the PC Serial card is installed correctly.
 - ii.) Ensure that other cards in the PC have not been upset.
 - iii.) Ensure that the power is connected and the PC is switched ON!
 - iv.) Ensure that the PC Serial I/O address is set correctly (Quad Port1 default is COM2 02F8h, Port2 default is COM3 03E8h, Port3 default is COM4 02E8h and Port 4 default is 198h. Lynx Port1 default is COM2 02F8h, Port2 default is COM3 03E8h, Port3 default is COM4 02E8h, Port 4 default is 180h and Ports 5 - 8 defaults are 1A0, 1A8, 1B0 and 1B8h, respectively.)
- If all these have been checked and the PC still does not power up then there is probably a conflict of I/O address between the PC Serial card and another board in the PC. Ask your dealer to check this or contact the HELP line as given on Intro. page 2.

CHAPTER 5

AT QUAD 4 PORT RS232 & AT LYNX 8 PORT RS232 SOFTWARE CONFIGURATION GUIDE

Introduction

This section contains the quick start software installation procedures for Serial Solutions for DOS, Windows 3.x, Windows 95 and Windows NT(the Serial Solutions installation is discussed in greater detail in the Serial Solutions Manuals, which come bundled with the Quad/Lynx card.) Also included are the software setup for OS/2 version 2.x, OS/2 Warp and SCO Unix / Xenix.

In each section, the worked example IRQ selections have been changed for indication only. You should change to these settings **ONLY** if you PC configuration allows this, refer to previous chapters for details on changing these settings. The setup procedures in this chapter also assume that your PC has only one serial port present. For more information on configuring the AT Quad 4 Port RS232 and AT Lynx 8 Port RS232 refer to Chapters 2 and 3 - “**AT Quad 4 Port RS232 Hardware Installation Guide**” and “**AT Lynx 8 Port RS232 Hardware installation Guide**” respectively. If you have changed the default settings of the cards in any way, then substitute the appropriate values in the relevant sections.

Informing The PC Of The Port Address.

The BIOS of most new PC's automatically detects whether serial ports COM1 - COM4 addresses are present in a machine. Other, older PC's are capable of detecting serial ports COM1 - COM2, but the problem comes with serial ports COM3 and COM4. PC's have a table of information that stores the setup of

the PC, this is the BIOS data area. It has space for 4 serial port addresses. The trick, for the older PC's, is to get the right addresses into the third and fourth port areas. However, PC's are not capable of recognising ports above COM4 - specific device drivers are responsible for this.

On the utility disk included with your card there are several programs for setting the COM3 and COM4 addresses. To set COM3 address from the DOS command line enter:-

ADDRCOM3 03E8 <return>

To set COM4 address from the DOS command line enter:-

ADDRCOM4 02E8 <return>

To set the COM port address from within the AUTOEXEC.BAT file use a text editor to add the following lines to the file:-

ADDRCOM3 03E8
ADDRCOM4 02E8

DOS 4, 5 and DOS 6 have features allowing access to COM3 and COM4. DOS 2 and DOS 3 only allowed access to COM1 and COM2, though some manufacturers their own DOS versions, e.g. COMPAQ, had enhanced MODE commands etc. to set up and use the extra ports. Please see Chapter 4, Serial Utility Disk for more details.

If you are uncertain how many serial and parallel ports are in the machine, it is wise to run the ADDRCOM3 program BEFORE installing an AT Dual RS232 series card type: -

ADDRCOM3 <return>.

The PC responds with something like:-

COM1: 03F8
COM2: 02F8
COM3: <not set>
COM4: <not set>
LPT1: 03BC
LPT2: <not set>
LPT3: <not set>

If the RS232 installation is attacked in this orderly manner, every thing should work first time. If it does not then check the software selectable communications parameters, Baud rate, Parity, stop bits first, and that the communications program is attempting to access the serial port installed. If this fails to solve the problem check the cable connections. Finally check that the card is indeed configured as you believed.

Settings for DOS Software.

Most users will require that the IRQ is set to correspond to the interrupt used by their serial communications software. **Note**, that a serial port that is USING interrupts must not share the same IRQ line as another serial port that is USING interrupts AT THE SAME TIME, otherwise some interrupts will be missed. IE no two ports may use the same IRQ line simultaneously.

Some serial communications software, especially older versions, assume that COM1 and COM3 both use IRQ4 and that COM2 and COM4 both use IRQ3. Other older packages assume that COM1 is on IRQ4 and that COM2, COM3 and COM4 all use IRQ3. Both kinds of older packages will therefore not allow simultaneous interrupt driven I/O on all four ports. It may be necessary to upgrade your serial communications software.

Newer, more up to date, serial communications programs are configurable. They allow the user to specify the I/O address and the interrupt used by the serial port. Procomm and many other packages are configurable in this way.

Serial Solution Configuration For Lynx Cards.

The Serial Solution software has been especially written to extract the highest performance out of the Lynx 8 Port RS232 card. The NewCOM.SYS device driver, the heart of Serial Solutions, needs however to be told that it is using the Lynx card and how the card is configured. The following is the CONFIG.SYS file entry that boots NewCOM.SYS ready to use the Lynx card in its default factory configuration. This assumes that the PC has one port, COM1, already installed. **N.B.** This software may not work correctly or work at all in Windows 3.x, Windows NT or Windows 95.

Figure 5-1 Lynx 8 Card With NewCOM.SYS.

```
DEVICE=NEWCOM.SYS /A3, 03E8 /A4, 02E8 /A5, 0198 /A6,  
01A0 /A7, 01A8 /A8, 01B0 /A9, 01B8 /L 03A0, 3,2,3,4,5,6,7,8,9  
/B 9 /S 512 /H, 4
```

PC already has COM1 installed on IRQ 4

Lynx card set as COM2 to COM9

All interrupts set to Shared

Shared Interrupt set to IRQ 3

The following shows a typical entry for NEWCOM in the CONFIG.SYS file when the PC already has two serial ports installed as COM1 and COM2. Remember to change the PORT 1-3 and SHARED IRQ jumpers to suit.

Figure 5-2 Lynx 8 as COM3-COM10.

```
DEVICE=NEWCOM.SYS /A3, 03E8 /A4, 02E8 /A5, 0190 /A6,  
0198 /A7, 01A0 /A8, 01A8 /A9, 01B0 /A10, 01B8 /L 03A0,  
10,3,4,5,6,7,8,9,10 /B 10 /S 512 /H, 4
```

- PC already has COM1 installed on IRQ 4
- PC already has COM2 installed on IRQ 3
- Lynx card set as COM3 to COM10
- All interrupts set to Shared
- Shared Interrupt set to IRQ 10

The following is the CONFIG.SYS file entry that boots NewCOM.SYS ready to use the Quad port card in its default factory configuration. This assumes that the PC has one port, COM1:, already installed.

Figure 5-3 Quad Card With NewCOM.SYS.

```
DEVICE=NEWCOM.SYS /A3, 03E8 /A4, 02E8 /A5, 0198  
/L 03A0, 3,2,3,4,5 /B 5 /S 512 /H, 4
```

- PC already has COM1 installed on IRQ 4
- Quad card set as COM2 to COM5
- All interrupts set to Shared
- Shared Interrupt set to IRQ 3

The following shows a typical entry for NEWCOM in the CONFIG.SYS file with the Quad port card when the PC already has two serial ports installed as COM1 and COM2. Change the dips to suit, see below.

Figure 5-4 Quad as COM3-COM6 NewCOM.SYS.

```
DEVICE=NEWCOM.SYS /A3, 03E8 /A4, 02E8 /A5, 0190 /A6,  
0198 /L 03A0,10,3,4,5,6 /B 6 /S 512 /H,4
```

- PC already has COM1 installed on IRQ 4
- PC already has COM2 installed on IRQ 3
- Quad card set as COM3 to COM10 shared IRQ 10.
- All interrupts set to Shared

On power up the PC will display the following messages:-

```
Serial Solutions serial port Device Driver V2.5 6th Jan 1993  
Copyright (c) 1990 - 1993  
Set address COM3 to 03E8h  
Set address COM4 to 02E8h  
Set address COM5 to 0190h
```

Set address COM6 to 0198h

Setup Lynx 8 Port card, status register at 03A0h with interrupt line 7

COM3 is card's port 1

COM4 is card's port 2

COM5 is card's port 3

COM6 is card's port 4

Setting number of Buffers to 10

Setting buffer size in bytes to 512

Figures 5-1 to 5-4 above contains several new command line switches for NewCOM.SYS that are not documented in the earlier Serial Solutions manuals. In all there are four new command line options, these are given in full later. A brief explanation is given now.

The /A switch is used to set the address of the chip used for a particular COM: port. Thus:-

/A3, 03E8 specifies COM3 has an I/O address of 03E8

/A4, 02E8 specifies COM4 has an I/O address of 02E8

/A5, 0198 specifies COM5 has an I/O address of 0198

/A6, 01A0 specifies COM6 has an I/O address of 01A0

/A7, 01A8 specifies COM7 has an I/O address of 01A8

/A8, 01B0 specifies COM8 has an I/O address of 01B0

/A9, 01B8 specifies COM9 has an I/O address of 01B8

This is the default setting for the Lynx cards port 1-8.

The /L switch is used to specify a multiport card with interrupt sharing is in use.

The parameters specify the SISR address, the interrupt line, and how the Lynx ports are assigned as COM ports. Thus:-

/L 03A0, 3,2,3,4,5,6,7,8,9

Specifies that the Shared Interrupt Status Register, SISR, is at I/O address 03A0 hex, that interrupt 3 is the shared interrupt line, and

that:-

Lynx port#1 is mapped as COM2

Lynx port#2 is mapped as COM3

Lynx port#3 is mapped as COM4

Lynx port#4 is mapped as COM5

Lynx port#5 is mapped as COM6

Lynx port#6 is mapped as COM7

Lynx port#7 is mapped as COM8

Lynx port#8 is mapped as COM9

The /B switch, /B 9, works as before and sets the number of buffers to 9. The 9 buffers are 1 for the (built in) COM1: port and one each for the 8 ports on the Lynx card.

The /S switch, /S 512, also works as before and sets the buffer size for the 9 buffers specified. This is a 512-byte input buffer and a 512 byte output buffer. When many ports are simultaneously in use in a PC then the larger the buffers the better especially at high baud rates. This allows more time for processing the data before any port's buffer becomes full.

I/O Address.

Switch: /A n,add

Switch: /A n-m,add NEW

Switch: /A n-,add NEW

Purpose:

Set the I/O address of one serial port, COMn.

Sets the I/O address of several ports starting at COMn.

'n' specifies the COM port. 'n' must be given.

If only 'n' is given only one ports address is set.

If 'n-m' or 'n-' are given then the addresses of all the ports in the range is set starting at the I/O address 'add'.

'add' is the address of the port, it must be in hexadecimal, and can be optionally suffixed with an 'h' or 'H'.

For example:

/A1,3f8 /a2,02f8H

Sets COM1 to 03F8H and COM2 to 02F8H.

For example:

/A3,02F8 /A4,02 E8 /A5,0198 /A6,01A0 /A7,01A8
/A8,01B0 /A9,01B8

Is used with the Lynx card to set the I/O address of the serial ports. The above line specifies COM3 to COM9, port#2-8 on the Lynx card. The built in COM1 port on the PC and the Lynx port#1 will both be found by the PC's BIOS on power up since they are at the default COM1 and COM2 addresses.

Number Buffers.

Switch: /B n

Purpose:

Set number of pairs of buffers to set up.

n is in range 0 to 16 and is the number of buffers to allocate. This is one factor which sets the maximum number of serial ports that can be used in interrupt mode. NewCOM reserves space for the buffers from main memory when the machine is booted.

For example:

/B 9

Reserves 9 buffers, one for the built in COM 1 port and one each for the 8 ports on the Lynx card.

For example:

/B 4

Reserves space for four pairs of buffers, enough for four serial

ports. The default is six pairs. The buffer allocated contains an equal amount of room for both the incoming data and the outgoing data.

DigiCHANNEL PC/4 and PC/8.

Switch: /D add,I,p1,p2.....

Purpose:

Set up one or more DigiCHANNEL cards. This command is entirely equivalent with the /L command with which it is interchangeable. One or two /D switches are required for each card, one for each of the two interrupt lines that the card uses. 'add' is the address of the status register for the first card. 'I' is the interrupt line. 'p1', 'p2', etc. are the COM ports that each of the card's ports will become. For example if p1 is '3', then port 1 on the card will be COM3. The places can be empty, indicating that that port on the card is not being set up to that interrupt. For example

```
/D140,7,,,5,6
```

```
/D140,2,3,4
```

sets up a DigiCHANNEL card with a status register at 0140H. The card uses interrupt lines 2 and 7. Ports 1 and 2 are designated as COM3 and COM4, and use IRQ 2. Ports 3 and 4 are designated COM5 and COM6, and use IRQ 7.

If more than one DigiCHANNEL card is installed in the machine then these can be linked together as shown in the cards' installation manual, in which case they would share the status register and interrupts of the first card. Install this combination as a single card, with one or two /D switches, one for each interrupt. The cards can be installed separately, each card using its own

status registers and interrupts. Note that although linked cards can share interrupts, separate cards cannot share any interrupt line.

The interrupt line here overrides any interrupts set via the /I switch (below), because DigiCHANNEL cards use a slightly different mechanism for interrupts.

Flynix-8 FAT-011.

Switch: /F i1,p1,p2,p3,p4,i2,p5,p6,p7,p8

Purpose:

Set up one or more Flynix-8 cards. One /F switch can be used to set up one or more cards.

'i1' is the interrupt line for ports 1 to 4 on the card.

'p1', 'p2', etc.

are the COM port allocation for the for the card. For example if p1 is '3', then port 1 on the card will be COM3. The places can be empty, indicating that that port on the card is not being used, or at least not being used via the interrupt sharing hardware on the card.

'i2' is the interrupt used by ports 5 to 8 on the card, designated by 'p5', 'p6', 'p7', and 'p8'.

For example

/F7, 3,4,5,6,2,,,15,16

Sets up a Flynix-8 card using interrupt lines 7 and 2. Ports 1,2,3 and 4 on the card are designated as COM3, COM4, COM5 and COM6 respectively, and use IRQ 7. Ports 7 and 8 on the card are designated as COM15 and COM16 respectively, and use IRQ 2. Ports 5 and 6 are ignored- it may be that they are not used at all, or that they will be used as standard serial ports. It is important to tell NewCOM about all the ports which are set to use the interrupt sharing hardware, and make sure that the ports that you plan not to use with interrupt sharing are disconnected from the sharing hardware. If more than one Flynix-8 card is installed in the machine then the same /F switch can be extended to include further cards:

/F i1,p1,p2,p3,p4,i1,p5,p6,p7,p8,i3,p9,p10,p11,p12,i4,p13,...

the second card's interrupts becoming 'i3' and 'i4', and its ports 1 to 8 becoming 'p9' to 'p16'.

The interrupt line here overrides any interrupts set via the

/I switch (below), because Flynix-8 cards use a slightly different mechanism for interrupts.

Hardware Handshake.

Switch: /H [n],[hs]

Purpose:

Select which hardware handshake type to use on port COMn.

'n' specifies the COM port. If n is not specified the handshake is applied to all serial ports.

'hs' is a number indicating the type of handshake, and 0 is the default. This does not override a previous XON/XOFF setting, in conjunction with which it may be used. The types are listed below and detailed under 'hardware handshakes' later.

For example:

/H1,2 Set COM1, handshake 2

/H,1 Set handshake 1 for all ports

The /H switches are processed from left to right, so for example

/H,2 /H1,0 /H2,1 would set COM3 to COM16 to handshake mode 2, COM1 to mode 0 and COM2 to mode 1.

The hardware handshakes currently supported are:

Type 0 RS232 DTR/CTS

Type 1 RS422 RTS/CTS

Type 2 RS485 Half duplex

Type 3 RS485 Send only.

Type 4 No handshake used, only TxD, RxD and Gnd need be connected.

Hardware Interrupt.**Switch: /I n,i****Purpose:**

Set interrupt lines for COMn.

'n' specifies the COM port. If n is not specified the interrupt line is applied to all ports.

'i' is the interrupt line in the range 2 to 7 and 10 to 15 or, to indicate no interrupt line, -1 or nothing.

For example:

/I1,4 set COM1 to use line 4

/i,-1 sets all ports to no interrupt

/i2, sets COM2 to no interrupt

The /I switches are processed from left to right, so for example

/I,3 /I1,4 sets COM1 to line 4 and COM2 to COM16 to line 3.

A serial port must be assigned an interrupt line before it can be used. On PC/XT/AT machines and EISA bus machines only one serial port can use an interrupt line. On PS/2 machines serial ports can share interrupts. Multiport cards with special interrupt hardware have different rules- see the information for setting up those cards.

When allocating interrupt lines to serial ports note that the six IRQ lines available to PC cards are traditionally designated as follows:

IRQ 2 Usually Free.

IRQ 3 COM2, COM3, COM4 etc.

IRQ 4 COM1

IRQ 5 LPT2:

IRQ 6 Floppy disk

IRQ 7 LPT1

IRQ 10 Usually Free.

IRQ 11 Usually Free.

IRQ 12 Usually Free.

IRQ 15 Usually Free.

Lynx 8 Port RS232 cards (May also use with Quad cards).

Switch: /L add,i,p1,p2...

Purpose:

Set up one or more Lynx cards. This command is entirely equivalent with the /D command with which it is interchangeable. 'add' is the address of the Shared Interrupt Status Register, SISR, set on the card.

'i' is the interrupt line set on the Shared IRQ jumper block.

'p1', 'p2', etc. are the COM port allocation for the Lynx card. For example if p1 is '3', then port 1 on the card will be accessed as COM3. The COM3 I/O address, ie the address of the Lynx card port#1, is specified elsewhere on the CONFIG.SYS file line, using the /A3 switch. The 'p' places can be empty, indicating those ports on the card that are not being set up to use the shared interrupt mechanism.

For example:

```
/L 03A0,3,2,3,4,5,6,7,8,9
```

Specifies that the Shared Interrupt Status Register, SISR, is at I/O address 03A0 hex, that interrupt 3 is the shared interrupt line, and that:-

Lynx port#1 is mapped as COM2

Lynx port#2 is mapped as COM3

Lynx port#3 is mapped as COM4

Lynx port#4 is mapped as COM5

Lynx port#5 is mapped as COM6

Lynx port#6 is mapped as COM7

Lynx port#7 is mapped as COM8

Lynx port#8 is mapped as COM9

For example:

/L 300,7,3,4,5,6

sets up a Lynx card with a status register at 0300H. The card uses interrupt 7 as the shared interrupt line. Ports 1 and 2 are designated as COM3 and COM4, Ports 3 and 4 are designated COM5 and COM6, and all the shared interrupt IRQ 7.

If more than one Lynx card is installed in the machine then these can be linked together as shown in the cards' installation manual, in which case they would share the SISRS, shared interrupt status register and interrupt line of the first card. Install this combination as a single card, with one /L switch.

For example:

/L 03A0,3,2,3,4,5,6,7,8,9,10,11,12,13

Specifies that the Shared Interrupt Status Register, SISRS, is at I/O address 03A0 hex, that interrupt 3 is the shared interrupt line, and that:-

Lynx card 1 port#1 is mapped as COM2

Lynx card 1 port#2 is mapped as COM3

Lynx card 1 port#3 is mapped as COM4

Lynx card 1 port#4 is mapped as COM5

Lynx card 1 port#5 is mapped as COM6

Lynx card 1 port#6 is mapped as COM7

Lynx card 1 port#7 is mapped as COM8

Lynx card 1 port#8 is mapped as COM9

Lynx card 2 port#1 is mapped as COM10

Lynx card 2 port#2 is mapped as COM11

Lynx card 2 port#3 is mapped as COM12

Lynx card 2 port#4 is mapped as COM13

Alternatively, the cards can be installed separately, each card using its own status registers and interrupts. Note that although linked cards can share interrupts, separate cards cannot share any interrupt line.

/L 03A0,3,2,3,4,5,6,7,8,9 1st card SISR at 03A0

/L 0300,7,10,11,12,13,14,15,16,17 2nd card SISR at 0300

The interrupt line specified in the /L switch overrides any interrupts set via the /I switch for the same COM ports, because Lynx cards use a slightly different mechanism for interrupts.

Buffer Size.

Switch: /S n

Purpose:

Set size of all buffers in bytes. n is rounded to the nearest power of 2, and must be in the range 32 to 32768. For any serial port opened two buffers of size n are allocated, one for input and the other for output. The space for the buffers is reserved by the driver when the machine is booted. For example:

/S 512

sets the buffer size to 512 bytes. The default size is 256 bytes.

Note that in actual operation only n-1 bytes are available, so the default buffer, nominally 256 bytes long, can only hold 255 bytes.

Software Handshaking.

Switch: /X n[,xon,xoff]

Purpose:

Set port COMn to XON/XOFF handshaking. In this mode the hardware handshake lines are ignored and the characters XON and XOFF are used to control the flow of characters on the serial line. The optional parameters XON and XOFF are decimal numbers which are to be used as the XON and XOFF characters. Their default values are 17 (DC1) and 19 (DC3) respectively. For example:

/X2 or /X3,18,20

If n, the port number, is not given, then XON/XOFF handshaking and any specified handshake characters are set for all ports, as /X or /X,18,20

Driver Defaults.

When no switches are specified in the CONFIG.SYS file the following defaults are used:

I/O Addresses.

On PC/XT/AT machines the ROM BIOS checks for COM1 and COM2 at their usual I/O addresses (03F8H and 02F8H respectively), and so these ports are automatically recognised. If a port is present at 02F8H only then this becomes COM1. IBM PS/2 machines recognise the first 4 serial ports are automatically.

Interrupt Lines.

COM 1- 4

COM 2- 3

COM 8- -1 (meaning none set)

Multiport Cards.

No multiport cards are assumed to be present.

Hardware Handshake.

All ports default to H0, the DTR/CTS handshake used by RS232 systems.

Software Handshake.

XON/XOFF handshaking is disabled and the characters are XON=17, XOFF=19, should software handshaking be turned on.

Buffer Size.

Buffers are 256 bytes long.

Buffer Number.

The maximum number of pairs of buffers is 6 (that is up to six ports can use buffered I/O).

Baud rate etc.


These depend on a variety of factors. Ports recognised by the ROM BIOS are reset to 2400 Baud, no parity, 8 data bits and one stop bit when the machine is powered up. The other ports reset to no parity, 5 data bits and one stop bit via the chip reset. They maintain their baud rates over a reboot, but tend to lose them if the machine is switched off, when they reset to approximately 1.8 Baud.

Buffer enabling.

When the machine is rebooted all buffers are deallocated. When a port is first used its buffers are allocated and enabled.

Serial Solutions Installation for Windows 3.x

To install the software from the supplied disk, insert the disk and assuming disk drive is drive A:, from Windows **Program Manager's** File menu choose "Run" and in the Command Line entry window type A:\SETUP (else type the letter of the drive you are installing from, followed by SETUP).




Selecting the "OK" button shows the setup program main screen, Figure 5-5, which will automatically select components for installation that have not been installed. Selecting the "Del All" button will select all installed components for deletion and selecting "Add All" chooses all uninstalled components for installation. For each component, there may be other selectable options, such as destination directories, by clicking on the button for the component; options may not be changed when the components are installed. For further details on the options for each component consult the README.TXT file on the supplied disk, this provides an update of the software on disk.

Note: If it is necessary to re-install an OLDER version of a component then the NEWER version component must be FIRST removed by selecting the component's button in the "Uninstall" column then selecting the "Continue" button.

If only logical ports COM1 to COM9 are to be used then de-select the Comms API library option by de-selecting the install

button for Comms API Library button in the "Install" column. This library is only necessary to allow the use of logical ports greater than COM9 e.g. COM10, COM11 etc.

Figure 5-5. Setup Program Main Display.



Selecting the **Continue** button will start the installation process. When the setup program has finished select the **Done** button. A Windows restart message will be shown only if the Windows communications driver option has been selected, and you should choose **Yes** to allow the new driver to run.


N.B. The installation procedure described below assumes that only one serial port is present on your PC.

Serial Port Installation


If your PC has only one COM port (COM1), and you are installing a Quad 4 Port card, click on **Control Panel** from the **Main Window**:



Then click on **Serial Ports**:





The following dialogue should then appear:



To add entries for a 4 port (QUAD) serial card (which supports interrupt sharing) you will need to add 4 extra COM ports. Select and click the **Add** button. The hardware settings (fig 5-6) window will be shown for COM2. The hardware settings of the serial port are entered, eg. in Figure 5-6 we have chosen a base address of 2F8 and an IRQ of 3 which is the standard setting for COM2. Note that the **multiport** button is selected which allows the values for the "SISR Base" and the "Card's Port" to be entered, which are only used for interrupt sharing. Since the first serial port on the card is at the base address of 2F8 (COM2), select this card's port value as 1. Assuming that the SISR address is the default of 3A0, select this from the available choices by selecting the downward pointing arrow in the "SISR Base" entry area.

Note: The base address, IRQ, SISR base address and card's port value should be entered correctly or Windows may crash when the serial port is used. For more details on SISR base address and card's port value see chapters 2 and 3 "AT Quad 4 Port Hardware Configuration" and "AT Lynx 8 Port Hardware Configuration."

Figure 5-6. Adding a QUAD Serial Card.**Figure 5-7. QUAD Card Comms Settings.**

Select the **OK** button to finish adding the port. This will display a Windows restart message, but do not restart until you have installed all four ports. It is necessary to restart Windows unless there are other serial ports which are to be added or changed **BEFORE** using any serial ports, in which case it is possible to restart Windows **AFTER** these changes are made.

Note: Adding a port automatically sets default values for communications settings as 9600 baud, no parity, 8 data bits and 1 stop bit. Refer to the following procedure if it is necessary to change the communications settings and/or hardware settings of a

serial port.

Changing Serial Port Settings

Change the communications Settings in the COM Ports to match the baud rate, parity settings etc. of the remote serial device and from the Advanced option in Settings change hardware settings to match the base address and IRQ physically set on the serial port cards. Below are a series of bullet points listing this procedure:

- Highlight the serial port required, e.g. COM2., in Serial Ports, Control Panel
- Click on the **Settings** button to change the communications settings, Figure 5-7.
- Click on the **Advanced** button for the hardware settings window, Figure 5-6.
- Enter the base address or choose one from the selections.
- Choose the Interrupt from the selections provided.
- Click on the **OK** button to exit the hardware settings window.
- Select the appropriate communications settings, which must match the communications settings on the remote terminal.
- Click on the **OK** button to leave the communications settings window.

To install further COM ports, e.g. COM3 - 5, repeat the above procedure the appropriate number of times.

Shared Interrupt Serial Port Setup Procedure.

This section describes how to configure Windows for shared interrupt multiport serial cards, ie those WITH special on board hardware that allows interrupt sharing, e.g. the Lynx 8 port or Quad 4 port cards.

For each serial port FOUR parameters MUST be set:

- The I/O address of the serial port card.
- The IRQ line the serial port is sharing.
- The shared interrupt status register address, which is used to set the card SISR address.

- Which port of the card is being configured, this is in the range 1-4 for a Quad card and 1-8 the Lynx 8 port card, unless there are multiport cards chained together.

Avoid Conflicts.

Again for the best results, i.e. trouble free comms, it is imperative that the shared interrupt used by the multiport serial card port is not used by any other device in the system. The I/O address and IRQ must, of course, match what is physically set on the serial port card.

Like the standard serial port card, when adding a multiport serial port card to a system:


- 1) Determine what ports are already installed and which IRQ's are already in use.
- 2) Set the new multiport serial port to avoid conflicting with existing devices.
- 3) Note the I/O address and IRQ setting on the new card.
- 4) Use the Control Panel Applet to configure the Serial Solutions for Windows driver, as follows:-

From **Program Manager**, go to the Main group, select the Control Panel then launch the Serial Ports applet by double clicking its icon.

Change the communications Settings in the COM Ports to match the baud rate, parity settings etc. of the remote serial device and from the Advanced option in Settings change hardware settings to match the base address and IRQ physically set on the serial port cards.

The following procedure shows this for previously set ports, but if you wish to add new serial ports, then repeat the steps shown in the section "**Serial Port Installation**". Consider, for example, adding a Quad port serial card. Figure 5-8 shows how the Serial Ports Applet display should look after adding the Quad serial port card, assuming only 1 COM port (COM1) was

Figure 5-8. After Adding a QUAD Card.



- Click on the serial port required, e.g. COM2.
- Click on the "Settings" button to change the communications settings, Figure 5-7.
- Click on the "Advanced" button for the hardware settings window, Figure 5-6.
- Enter the base address or choose one from the selections.
- Choose the Interrupt from the selections provided.

If you have a multi port interrupt sharing card AND wish to use interrupt sharing then follow steps f1) and f2), as shown below:

For a multiport interrupt sharing card only:

- Enter/select the SISR base address (default is 3A0).
- Enter the Card's Port, this is the physical port on the card.
For this port COM2 enter Card's Port = 1.

This example assumes a 4 port card is being set as COM2, COM3, COM4 and COM5, all sharing IRQ15, with SISR register at 03A0 hex. So the settings for all the 4 ports would be:-

COM Port COM Base SISR IRQ Card's Port
COM2 0180 3A0 15 1 = First port on card
COM3 0188 3A0 15 2 = Second port on card
COM4 0190 3A0 15 3 = Third port on card
COM5 0198 3A0 15 4 = Fourth port on card

If logical ports COM6-COM8 are not available from the main window, add these ports using the "ADD" button in the main window.

- g) Click on the **OK** button to exit the hardware settings window.
- h) Select the appropriate communications settings, which must match the communications settings on the remote terminal. Click on the **OK** button to leave the communications settings window.

Deleting Ports in Windows.

The **Delete** button can be used to discard the entries of ports that have been removed from the system.

Note. Never try to leave out a serial port number when using the delete button, because Windows can automatically shift serial port numbers which results in a mis-match of settings in the Serial Ports Applet (COM1-COM4 only).


Restarting Windows.

Whenever certain values have been entered or changed in the hardware settings window, a message prompting to restart Windows will appear. Only after having made ALL the necessary changes restart Windows so that the new settings come into effect. **Note:** Default for communications are given whenever the ADD button is used, 9600 baud, no parity, 8 data bits and 1 stop bit.


Serial Solutions Installation for Windows 95 & 98.

The following steps describe the installation of the Serial Solutions driver for Windows 95, which is supplied, on one 3.5" floppy disc. The listed installation procedure assumes that only 1 COM port (COM1) is present.

Open the **Control Panel** - there are several routes to the **Control Panel**, the simplest is to open the **Start** menu and select **Settings**.



Double click the **Add New Hardware** icon in the control panel.




Click **next** on the applet dialogue.



The **Add New Hardware** wizard will ask you if you wish Windows to search for your hardware. Click the **No** radiobutton since Windows cannot find Multiport Serial Solutions serial ports and it will save some time. Click **next**




From the hardware types list on the next page select **Multi Function-Adapter**. Click **next**.




Select **Multi Function PC Card Parent** and then click **Have Disk**.



Windows will then ask you for the location of the Serial Solutions files, assuming your floppy drive is designated A:, you will see the following:




After the installation procedure, the Window will display a list of Serial Solutions cards:



Select the **ISA 8-Port RS232 Card (IRQ Sharing)**. Click **Next**.

Windows 95 will then inform you of the settings it has assumed for the new ports, these values are likely to be the factory default settings for the Lynx card, though if any one these values are in use another range will be chosen. Since these values are selected by Windows 95 itself, they will not be conflicting ones. Make a note of these settings in case card settings need to be changed. Click **next**.



Click **finish**. Windows will install the card with the listed settings.




You will then be asked if you wish to re-boot the system. Since the multiport card will now need to be installed, select yes. Turn the PC off and insert the multiport card as described in chapter 3, making changes to settings on the card as necessary. Restart the computer and allow Windows 95 to load normally. Upon loading it will then "detect" each of the ports on the Lynx card individually and install them, in a similar manner to that of a Plug and Play card.

However, if you choose not to restart your PC Windows 95 will still "detect" each of the ports on the Lynx card as described


above, despite the card not being installed - this is due to the nature of the driver software.

Multiport Card Settings in Windows 95 & 98.

Upon installation of the Lynx card and Windows being restarted, the **Device Manager** will appear similar to the following:



To change settings of the parent device (the Lynx Card), double click the Lynx card entry under the **Multi-Function adapter** branch, and select the Serial Solutions Tab:



PCI Quad RS232 Users: The Port Select buttons are not available.

The adjustable options available in this window are:

1. **SISR base address.**
2. **Shared IRQ.**
3. **Card ID.**
4. **IO Range.**
5. **IRQ.**
6. **Bank IO address.**
7. **Port Select Buttons (Lynx Cards only)** - Allows the user to switch between views of ports 1 -4 and Ports 5- 8.
8. **COM Port Assignment** - see the section below "Changing COM port numbers"


Refer to Chapter 2 or Chapter 3 - Quad and Lynx Hardware Configuration for a more detailed explanation of these terms

The first six listed values may be changed freely to suit the users preferences, though if the suggested setup procedure has been followed (install Serial Solutions, then install card) there will

be no need to change them, as the assigned values will not be conflicting with anything.

Changing COM Port Numbers in Windows 95 & 98.


In the Serial Solutions tab of the parent device properties window the COM port assignment may be changed, simply by selecting a new COM port value from the pull down menu relevant to the port. However, COM port usage other than those for the installed multiport card itself are not checked, so it is advisable to first check which COM ports are in use - port availability can be checked by viewing the Device Manager:



All COM ports present will be listed under the entry "**Ports (COM & LPT).**" The above screenshot indicates that COM11 and above are not installed, and therefore may be used.

Multiport Card Port Settings In Windows 95 & 98.

Double clicking upon an individual port entry in the **Device Manager**, and selecting the **Port Settings** tab will display:




Settings available in this window are:

1. **Baud Rate.**
2. **Data Bits.**
3. **Parity.**
4. **Stop Bits.**
5. **Flow Control.**
6. **Restore Defaults** - When clicked, this will reset the selected port to the default values of:

Baud Rate:	9600
Data Bits:	8
Parity:	None
Stop Bits:	1
Flow Control:	Xon / Xoff

Selecting the **Serial Solutions** tab of the selected port properties Window will display:



Settings available in this window are:

1. Shared Interrupt Settings -

- **Enable Sharing** - Clicking on this setting will remove the selected port from the shared interrupt, and will require the particular port to be assigned its own unique IRQ value from the Resources Tab.
- **SISR address** - This value is used in conjunction with the **Enabling Sharing** checkbox, and will appear greyed out if the Enabling Sharing checkbox has been un-checked.
- **Port Index** - This is only used for interrupt sharing cards. Card ID refers to the card position when multiple multi-port cards are linked (or chained) to share an interrupt. The 1st card has a card ID of 0, and the 2nd card in the chain has a card ID of 1 etc. The factory default Card ID is 0.

Refer to Chapter 6 - "**Shared Interrupt Settings**" for further information on interrupt sharing.


2. FIFO settings.

- **Enable FIFO** - turns the selected ports FIFO buffer on or off. It is strongly recommended that the FIFO for both ports is left enabled.
- **Receive Buffer** - These settings allow the selection of a receiver FIFO trigger setting. Selecting a low value will allow the interrupt to be serviced quicker, which is good for slow machines. If you have a fast machine, setting a high value will give you more time for multi-tasking operations.
- **Transmit Buffer** - These settings allow the selection of a transmitter FIFO trigger setting. Selecting a low value will send fewer data-bytes per interrupt, and this is recommended if you are communicating to a slower machine. Selecting a high value will send more data-bytes per interrupt, and will give more time for multi-tasking operations.

Restarting Windows

Whenever certain values have been entered or changed in the hardware settings window, a message prompting to restart Windows will appear. Only after having made ALL the necessary changes restart Windows so that the new settings come into effect.

Windows 95 issues a warning to ask you to confirm your changes and asks you if you wish to shut down the computer. If you have more ports to configure select No, otherwise select Yes.



After the computer has been re-booted the new ports should be available for use.

Serial Solutions Installation for Windows NT 3.51 & 4

The suggested installation sequence is:

Check Windows NT's I/O Use, to determine which IRQ's and I/O addresses are already in use on your PC, and thus which are available. See the appropriate section below.


Configure and install the serial card, noting the settings of jumpers and switches.

Run the Multiport setup control panel.

Note that to install this software or change serial port settings under Windows NT you must be logged in as a user with Administrator level privileges, consult your NT documentation to see how this can be set.

Checking Windows NT 4 I/O Usage


The simplest way to find out which I/O addresses and IRQ's are potentially available for the serial cards is to examine those that Windows NT believes are free. This can be done through the **Windows NT Diagnostics**. From the **Start Menu** choose **Programs, Administrative Tools (Common)** and **Windows NT Diagnostics**. Click the **Resources** tab, and if the **IRQ** button is not selected, select it.




A list of in use IRQ's is shown (those shown above include a four port multiport card using the shared interrupt of 5). Any interrupt not shown on the list can be used, make a note of a free IRQ and set the card to use it, a list of recommended free IRQ's is given elsewhere in this manual. Also click the **I/O Port** tab and make a note of a free address space for the card. Each port will require 8-bytes of space and banked ports need this space to be consecutive (for example a 4 port card with all ports enabled and banked will require 32 consecutive bytes of I/O space. Select **OK** to clear this dialogue. This setup continues with the “**Configuring and Installing the Serial Card**” section below.

Checking Windows NT 3.51 I/O Usage

The simplest way to find out which I/O addresses and IRQ's are potentially available for the serial cards is to examine those that Windows NT believes are free. This can be done through the **Windows NT Diagnostics**. From the **Administrator** program group double click **Windows NT Diagnostics**.



Click the IRQ/Port Status button. (In addition to viewing the settings you can print them from the Print option on the File menu whilst on this dialogue.)



The top pane of this window lists the interrupts (or **Vectors**) in use on this computer, you need to find an interrupt which is not on this list for your card.

The bottom panel lists the physical addresses that are in use on your computer, a free block needs to be found with 8-bytes free for each port that you will be configuring on your card.

Configuring and Installing the Serial Card

Install the serial interface card in an available slot. Depending on the type of cards being installed, and how they are configured, you should note the configuration of each serial port: If you are not using the Shared Interrupt Mechanism (for more information see Chapter 6 “**Quad and Lynx Shared Interrupt Mechanisms**” and relevant sections of Chapters 2 and 3) for any ports, note:

The input/output address. (The relationship between the COM1, etc. jumper positions and the input/output address, which should be documented in the relevant manufactures hardware manual.)

The IRQ number you are using. N.B. If any ports are using the *Shared Interrupt Mechanism* note:

The Shared Interrupt Status Register (SISR) address (the default for Serial Solutions cards is 3A0hex).

The Card ID (the default for Serial Solutions cards is 0). Each logical card has 8 ports on, so the Card ID is set in units of 1 (0 to 7) for 8 port serial cards and units of 0.5 (0 to 3.5) for 4 port serial cards.

Installing the Serial Solutions Software

To install the software from the supplied disk, from Start Menu choose "Run" and in the resulting window type:

A:\SETUP

Selecting the "OK" button begins the conventional InstallShield setup process, there are no options for this installation, all items must be installed in the NT System32 directory. Once the software has been installed, you may run it from the Control Panel.

Issues in Configuring the Serial Solutions Software

Open the Control Panel, (NT 4 double click on **My Computer** and then on **Control Panel**, NT 3.51 open the **Main** group and double click on **Control Panel**). Before running the Serial Solutions Multiport applet, if the new card you have installed has a port configured to use as COM 1, 2, 3 or 4 then it is possible that NT will have created default settings for this port - this port should then function as normal. However this port can only be modified using the default Windows NT Ports control panel, this program will be unable to modify the settings for this

port. If one or more ports are automatically detected then you have two options :

Delete Detected Port

The simplest option is to **delete** the existing port and recreate it using the Serial Solutions software, to do this :

Double click on the Ports control panel applet.

Select the port on the list which has been detected and select **Delete**.

Press OK.

Close the Ports applet and then start the Multiport applet. You may now configure the port you have selected using the software as normal.

Keep Detected Port

You may keep the port automatically created by NT and then omit that port by clearing the check box in the wizard (see later sections for further information) when creating settings for the new card. So for example if port 2 has been detected as COM 3 on the card and you wish to keep this port then when setting up the card using this software set the **enable** option box on port 2 to off. The program will then not create settings for this port and so NT will continue to use the existing ones. You will need to modify settings for that port using the standard NT control panel.


Configuring the Serial Solutions Software

To begin setting up your multiport card select the Multiport applet. (Please note that though the following screen

dumps are from NT 4 the setup procedure for NT 3.51 is exactly the same.)




This will launch the Serial Solutions Setup Wizard for Windows NT.



This introductory screen will warn you if you are running the program without administrator permissions (you are not allowed to continue if this is the case since you cannot alter settings). If all is

well it will appear as above. When you are ready to continue click **Next**. Note that at any stage in the use of this wizard clicking the Cancel button will terminate setup without any changes having been made. Only when a **Finish** button is pressed will settings be committed.



You will now be shown a list of serial ports that were installed on your computer when NT was started. If you have since installed a serial port without restarting, or you have installed a serial port that is not functioning correctly, it might not be shown on this list, be aware of this in these situations.

There are now four options for continuing:

The default is to add another card, to do this ensure that the **Add another multiport card** radio button is selected then click **Next**.

If you have previously installed a Serial Solutions multiport card you will see entries in the lower list. You can then :


Modify one of the above multiport cards, select the card you want to change and the appropriate radio button and click **Next**.

Delete one of the above multiport cards, select the card you want to delete and the appropriate radio button and click **Next**.

Delete all multiport card settings, this will remove entries for all cards in the list.


Add Another Multiport Card

The first step when adding another multiport card is to specify the number of ports that the card has and an optional identification name that you give to the card.



You set the number of ports on your card using the appropriate radio button. This must be the total number of ports on your card, even if you do not want to use all of them (individual ports can be disabled later). An optional name can be entered for the card, this allows it to be identified when a number of multiport cards have been installed. In the above example an eight port card


(the default), which has been called “Eight Port Card”. Once these entries are present click Next to continue configuring your card.



You are now ready to begin configuring ports. This dialogue is in two separate sections, the four boxes along the top are to allow you to configure individual ports. The box in the lower part of the dialogue is for settings shared amongst the ports. These settings follow closely those which may be set on the card itself (these settings must match of course).

Configuring Ports

The values for each port are as below:



Port enable option - This allows a port to be omitted from this setup, clearing this tick box ensures that this program will generate no settings for this port. This port can be left deactivated or can be setup using a separate port setup program.

COM 1 to COM 4 settings - Under Windows NT any COM port can use one of the standard COM port addresses (from 1 to 4), this part of the dialogue allows you to assign one of these addresses to a port. (In the examples shown above a port is already using the COM 1 and COM 2 addresses and so these may not be selected). How a port is given a COM number depends on what other COM ports exist on the machine. In an example where port 2 on the card is set to use COM 3 with the appropriate radio button then :

If a COM 3 exists (using some other address, since the default COM 3 address is free), setting a port to use COM 3 will use the COM 3 address but its COM port number will be generated from the Base COM port value (see below). If for example Base COM is 18 then this port will be COM 19.

If no COM 3 exists, a standard COM 3 will be created, using the COM 3 address and called COM 3.

Both of these situations are independent of the IRQ setting.

Bank Address setting - The alternative to giving a port a standard address (one of the COM 1 to COM 4 values) is to give it an address based on the bank address (see below). If the BANK radio button is set this port will be given an address based on the bank address. For example if all ports are banked (and the bank address 180 is being used) port 1 is given the address 180, port 2 188, port 3 190 and so forth.

IRQ setting - This is the IRQ value that a port will use, each port can use its own individual interrupt value or the shared interrupt

value (see below). Only the interrupt values which can be set on the card are available on this list for obvious reasons.

Shared Settings

There are four shared settings, if all ports are set to use one of the default COM port addresses and their own interrupt (which is not possible on an eight port card) then these settings do not matter. However to use shared interrupt settings these settings are important.

IRQ - This is the shared interrupt request value, any port whose IRQ has been set to Shared will use this interrupt value. Again only those interrupts which may be selected on the card are available on this list.

Base COM - This is the COM port number of the first active port on the card. Settings will be generated for the first enabled port to use this value and the second enabled port to use this value plus one and so on. If port 2 is disabled (or using a default COM port number, as above) then ports 1 and 3 will be given consecutive COM port numbers.


SISR - This is the Shared Interrupt Status Register, this is a register which handles shared interrupt events, a valid address must be given. Suitable settings for the SISR are listed elsewhere in this manual.

Bank Address Ports - Ports that are not using one of the default COM 1 to 4 addresses are given an address based on the bank address. The first active port is given the bank address and the next is given the bank address plus 8 and so on.

Card Type Differences


The screen above shows the first stage of configuring an eight port card, ports 5 to 8 are configured after the **Next** button is pressed. Cards with fewer ports can be configured entirely on this screen

(the dialogue looks somewhat different then, as in the two port example below) and so pressing **Next** will complete the entry of settings for the card. In this case skip the next section.



Configuring Ports 5 to 8 (8 Port Cards Only)

When installing an eight port card the last four ports are configured on the next pane of the wizard that is shown below.



The configuration for these ports is somewhat different to that for the first four since they cannot be set to a default address (they must be banked or disabled). For each port only two pieces of information are necessary:


Enable - If this box is checked then this port will be configured, if it is clear then this port is omitted.

IRQ - This as before allows you to set an interrupt value for each port, this can be one of the normal values or shared.

The other values for these ports (COM port number, interrupt value, SISR and address) are generated from the shared settings created on the previous dialogue. These values are shown for reference at the bottom of the dialogue, to change them click the **Back** button. When you have created settings for the remaining ports click **Next**.


Completing Card Setup

Having entered all settings for your card you will be shown a summary of the settings you have entered on a port by port basis.



These values have not yet been created, to enter them into the registry click **Finish**. If you want to change any of these settings click the **Back** button. You may print a copy of this report to the default Windows printer using the **Print** button.

The example shown above is a card installed using the defaults on a machine with an existing COM 1 and COM 2. Since COM 2 exists, interrupt 3 has not been used. Note that though this has created a COM 3 and 4 they are banked (i.e. using the Bank address rather than the default addresses for these ports). These addresses are then free for use by other ports later.




Having clicked **Finish** you will be asked if you want to restart the computer to create these ports. Before you can use the ports you must restart the computer, to do this click **Yes**. If however you


want to add more ports before restarting then click **No** and restart the wizard.

Modifying Settings for a Multiport Card

When card settings have been created you can later modify them using this same control panel. Run this control panel again and when you select **Next** from the Welcome dialogue, the option screen will show the previously installed card. In this example an eight port card called “Eight Port Test” using COM 3, COM 4, COM 5, COM 6, COM 7, COM 8, COM 9 and COM 10.




To modify settings for this card click on it in the list, choose the **Modify one of the above multiport cards** option and click **Next**.



A report is then shown as above on the ports configured on the card you have selected. You may print a copy of this report to the default Windows printer using the **Print** button. On this screen you may change the name of the card (which is optional) or choose Next to change settings.


The settings screens are the same when modifying a card as when first creating the values, but instead of loading the defaults the settings screens are shown with the program defaults. Having entered new values you will be shown a report giving the new values for this card (which in this example are unchanged).



When you click **Finish** you will again be asked to restart your computer. If you have changed settings and want to use the new settings you should click **Yes** and the control panel will restart the computer. Clicking **No** will allow you to restart later but your new values will not be used by NT until the machine is restarted. To exit without making changes choose the **Cancel** button.

Deleting Settings for a Multiport Card


When card settings have been created you can later delete a cards settings using this same control panel applet. This option deletes all settings for all ports on a single card. To delete a single port use the **Modify Settings for a Multiport Card** option and disable the required port. As in Modify Settings choose the card that you want to delete from the list on the **choose function** dialogue and the **Delete Settings for a Multiport Card** option and click **Next**. You are then shown a report on the card which you have chosen to delete.



Clicking on **Finish** will then delete this cards settings. You will be asked if you want to restart the computer, click **Yes** to restart and update your COM port settings or **No** to continue and restart later. Clicking **Print** will send a copy of the report to the default Windows printer.

Deleting All Multiport Card Settings

When card settings have been created you can later delete all card settings using this same control panel applet. This option deletes all settings for all ports on all cards, it removes all current values. To do this you do not need to choose the card from the list, simply choose the **Delete Settings for a Multiport Card** option (from the **choose function** dialogue) and click **Next**.



You are then given important information on the deleting process and the option to delete or not delete the *Permit Share* Registry key. This key is important to the operation of multiport cards. If you have other multiport cards in your computer which you did not setup using this Serial Solutions software then you must ensure that the **No (leave the PermitShare key enabled)** option is enabled, otherwise the other cards may not function correctly. If however you are deleting all multiport settings then it is safe to use the default **Yes (no other multiport cards installed)** option to reset this keys value. (If this program is used to install another card at a later date this key will be recreated).

Clicking Finish will delete all the card settings. You will be asked if you want to restart the computer, click **Yes** to restart and update your COM port settings or **No** to continue and restart later

Configuring Ports in OS/2 Version 2.x and OS/2 Warp.

OS/2 provides built in support for up to four serial ports. OS/2 assumes that COM1 is on IRQ4 and that COM2 is on IRQ3. To use COM3 and COM4 ports on AT bus machines it is necessary to include parameters on the DEVICE=COM.SYS statement in the CONFIG.SYS file. That is:-

DEVICE=COM.SYS (N,XXX,I)

where N is the COM port number (3 or 4)

XXX is the I/O port address (3E8, 2E8, etc.)

I is the IRQ (interrupt) level (from 1 to 15)

For COM2 using IRQ3 the CONFIG.SYS file entry should be:-

DEVICE=COM.SYS (2,2F8,3)

For COM3 using IRQ10 the CONFIG.SYS file entry should be:-

DEVICE=COM.SYS (3,3E8,10)

For COM2 using IRQ 3 and COM3 using IRQ10 the CONFIG.SYS file entry should be:-

DEVICE=COM.SYS (2,2F8,3) (3,3E8,10)

Ensure that a 1 space character is between each of the bracket enclosed variables. When using OS/2 note that these settings DO NOT get passed on to the WINOS/2 control panel but also have to be set as for Windows 3.1, see above.

If the standard COM3 or COM4 addresses are not used, and a mouse is on COM1/2, in DOS VDMs the ADDRCOM3/4 programs may report COM port addresses in a different order to that expected. However the MODE command etc. correctly accesses the right port in both DOS VDM and OS/2 sessions.

Please Note:

As with Windows 3.1, OS/2 STRONGLY recommends, and automatically detects, the use of 16550 FIFO chips on serial

ports.

Configuring Ports in SCO Unix / Xenix.

This section describes how to install the AT Quad 4 Port RS232 port and the AT Lynx 8 port cards for use with the built in support provided by the SCO Unix and SCO Xenix operating systems.

When set to the correct I/O addresses etc., the Lynx and Quad cards are automatically recognised by the Unix kernel as it boots and so the cards can be used "straight out of the box". This built in support is no longer supported by SCO Open Server version 5. Whilst this built in support suits many users, it allows only two configurations and so is of limited flexibility.

The jumpers and DIP switches on the card have NOT been set to the SCO UNIX defaults, instead the card is configured for MS DOS use, therefore it is necessary to change the settings to match those selected by the system administrator when using the SCO CUSTOM utility.

Optional Custom Driver and Installation Script.

Unix and Xenix drivers with installation scripts come in the AT QUAD UNIX and AT LYNX UNIX packages and are also available separately. These drivers and scripts allow a free choice of interrupt vector, port I/O addresses etc.

AT Quad 4 and the AT Lynx Under SCO Unix.

The Lynx and the Quad port card can be each set to one of two configurations, shown below in table 5-1, so that they will be recognised automatically by the Unix system.

Table 5-1 - Quad and Lynx card Unix Configurations

	Quad Card	Lynx Card	
Config A	IRQ Vector	4 (COM1)	4 (COM1)
	BANK address	110-12F hex	110-14F hex
	SISR address	150-151 hex	150-151 hex
Config B	IRQ Vector	3(COM2)	3(COM2)
	BANK address	210-22F hex	210-24F hex
	SISR address	250-251 hex	250-251 hex

If interrupt vector 4 is free then select configuration a).

Else, if interrupt vector 3 is free then select configuration b).

If neither interrupt vector is free then order a copy of custom Unix and Xenix installation scripts from your supplier.

If you already have COM1 installed avoid IRQ4, ie Vector 4.

If you already have COM2 installed avoid IRQ3, ie Vector3.

You may only use the above interrupt vectors if you do not have COM1 and/or COM2 installed.

SCO Unix/ Xenix Jumper Settings.

Table 5-2 (below) show the two Quad port configurations, whilst Table 5-3 (below) show the two Lynx 8 port configurations. For more information on configuring the AT Quad and AT Lynx refer to Chapters 2 and 3 - “**AT Quad 4 Port RS232 Hardware Installation Guide**” and “**AT Lynx 8 Port RS232 Hardware installation Guide**” respectively.

Table 5-2. Quad Port SCO Unix/Xenix Configurations

	Config (a)	Config (b)
COM 1	BANK	BANK
COM 2	BANK	BANK
COM 3	BANK	BANK
COM 4	BANK	BANK
IRQ VECTOR	4 (COM 1)	3 (COM 2)
BANK ADDR.	110-12F hex	210-22f hex
BANK SISR.	150-151 hex	250-251 hex

Set the jumpers as per your requirement and place the card in the PC (refer to Chapter 4 -“**Installing your PC card**”). Start the Unix system in maintenance mode and execute the /etc./mkdev serial (ADM) command, installing card as a Digiboard PC/4 card. This creates the necessary device files, new kernal etc. allowing access to the new terminal ports. Finally reboot the PC using the shutdown (ADM) or reboot (ADM) commands. On power up the card should be recognised as a Digiboard Digiport PC/4 card.

Table 5-3. Lynx Port SCO Unix/Xenix Configurations

	Config (a)	Config (b)
COM 1	BANK	BANK
COM 2	BANK	BANK
COM 3	BANK	BANK
COM 4	BANK	BANK
IRQ VECTOR	4 (COM 1)	3 (COM 2)
BANK ADDR.	110-14F hex	210-24f hex
BANK SISR.	150-151 hex	250-251 hex

Set the jumpers as per your requirement and place the card in the PC (refer to Chapter 4 -“**Installing your PC card**”). Start the Unix system in maintenance mode and execute the `/etc./mkdev serial (ADM)` command, installing card as a Digiboard PC/8 card. This creates the necessary device files, new kernel etc. allowing access to the new terminal ports. Finally reboot the PC using the `shutdown (ADM)` or `reboot (ADM)` commands. On power up the card should be recognised as a Digiboard Digiport PC/8 card.

CHAPTER 6

QUAD AND LYNX SHARED INTERRUPT MECHANISMS.

Introduction.

This chapter discusses the shared interrupt mechanism used on the Lynx 8 and Quad port RS232 cards and the Quad RS422/485 cards. This interrupt system is 100% compatible with that used on the Digiboard PC/8 and PC/4 dumb cards. The extensive range of software written for the Digiboard cards will work with the Lynx 8 and 4 port cards.

Digiboard Compatibility.

The Lynx 8 port and Quad port cards are 100% Digiboard PC/8 and PC/4 compatible. They also have additional features allowing them to be used in far more applications than the original Digiboard products. These include half size Quad and Lynx card, AT interrupts 10, 11, 12, 14 and 15 and interrupt chaining for up to 7 boards.

Why Do We Need A Shared Interrupt Mechanism?

In the standard PC design, only IRQ2-7 are available on the expansion bus, COM1 was allocated to use IRQ4, whilst COM2-8 all are allocated to IRQ3. Due to limitations in the standard PC design, only one device can be actively using interrupts on any particular IRQ line at a time, thus COM2 -COM8, can only have one interrupt driven serial port BETWEEN them and the other 6 must use the substantially slower polled RS232 input output. On a 4 and 8 port serial card this will slow down throughput considerably and may cause input data to be lost on those ports without interrupts.

Both Serial Solutions Software and the Lynx 4 & 8 port serial cards implement interrupt sharing. Any or all of the serial ports can share a single interrupt line. As well as hardware allowing sharing of a single interrupt, there is a shared interrupt status register.

Shared Interrupt Status Register.

The shared interrupt status register uses a PRIORITY encoding system. If when reading the Shared Interrupt Status Register (SISR), 0FF Hex is returned there are no interrupts pending. It returns 00 Hex if Serial Port 1 has an interrupt pending, it returns 03 Hex if Serial Port 4 has an interrupt pending, it returns 07 hex if Serial Port 8 has an interrupt pending. Reading the SISR does NOT clear the interrupt condition, that must be cleared by servicing the serial port chip in the normal way. The first interrupt generated is latched, successive interrupts received between the first interrupt being generated and serviced will be queued and prioritised. The higher priority port will always override interrupts from the lower priority port. For best results place those devices with higher baud rates, or higher data rates (=same baud rate but more data) on the higher priority ports. The latching of the first interrupt and the queuing of later ones means that no one port can permanently lock out other ports, and is a good method of ensuring fairness.

Figure 6-1. Shared Interrupt Priority.

Port	Priority	Shared Status Register
No Interrupt	None	FF Hex= 256 decimal
Port 1	Highest	01 Hex= 1 decimal
Port 2	High	02 Hex= 2 decimal
Port 3	High	03 Hex= 3 decimal
Port 4	Middle	04 Hex= 4 decimal
Port 5	Middle	05 Hex= 5 decimal

Port 6	Low	06 Hex= 6 decimal
Port 7	Low	07 Hex= 7 decimal
Port 8	Lowest	08 Hex= 8 decimal

The first interrupt generated causes all successive interrupts to be "hidden" from the SISR, until the interrupt it has been serviced.

Later interrupts are prioritised so that those of lower priority have their interrupt "hidden" from the SISR, until the interrupt on the higher priority port has been serviced.

The Shared Interrupt Register address is set by 9 DIP switches on the card and there is a jumper block to select which PC interrupt line the Shared Interrupt Register is to drive.

Last Card Settings.

Both the Quad and Lynx port card use DIP4 of the CARD ID block (position indicated on Figure 2-1 and 3-1, respectively) as means of identifying whether or not they are LAST in a system. When DIP4 is set to ON the card is LAST, and when it is set to OFF it is NOT LAST.

DIP 4 ON = LAST CARD DIP 4 OFF = NOT LAST CARD



If only one multi port card is in the PC then DIP4 should be set to ON, since the card is both the first and LAST card present; if a system with more than two cards is installed ONLY ONE card should be set to last, all others should be set to not last.

One Lynx Card Systems.

When only one Quad card is installed in the PC system, the situation for the vast majority of users, then the multi card chaining system must ALWAYS be set in a certain way. The

CARD ID switch MUST always be set to 0, i.e. DIP 1-3 ON. The LAST setting, DIP 4 on the CARD ID should be set to ON (LAST CARD = YES). This is configuration is shown below in Figure 6-3, “**card ID in 1 Lynx card system**”

The two wire chaining cable supplied with the card should not be used, it is only required in multi Quad card systems. Refer to Chapter 6 - “**Shared Interrupt Mechanisms**”, and more specifically the section entitled “**Multicard setup**” for a more in depth discussion on this subject.


Figure 6-2. CARD ID In 1 Lynx Card System.

CARD ID:



Note: On 1 Lynx Card System CARD ID = 0
 DIP 4 = ON (Last Card)

MULTICARD ID:



Multiple Card Setup.

For users who require more than just 4 or 8 serial ports per PC, the Shared Interrupt mechanism can be extended to a maximum of 7 boards, providing a total of 56 serial ports per PC! It is highly recommended that the FIFO buffered serial port chips are used when more than 8 ports are added to the computer. The benefits of the chaining mechanism, is that all the serial ports set their Shared Interrupt Status Register to the same I/O address thus providing no extra overhead in the servicing software code, and all


the Lynx cards use the same shared interrupt IRQ line in to the PC, thus conserving scant PC resources. Of course, if the user wishes each Lynx card can be set to use its own unique Shared Interrupt Register, without any need for interrupt chaining. In this case each card is set to ID=0 and the SISR address of each card is set to a different value. This provides faster throughput with many serial ports.

To implement the chaining the two wire cable supplied with each card is used to carry forward the one card's interrupt to the next card in the chain. Thus to a card in the middle of the chain, one cable brings the external interrupt IN from boards of the higher priority, and one cable carries the interrupt OUT to boards of a lower priority. Each card has a different CARD ID that identifies which board generated the interrupt. Figure 6-3 shows the CARD ID switch settings. Note: do not pick arbitrary CARD ID values. The 1st Lynx/Quad port card must be set to CARD ID =0, as it is the highest priority card, the second Lynx/Quad card must be set to CARD ID 1, the third Lynx/Quad card must be set to CARD ID 2 and so forth. Each card's CARD ID is set independently of the I/O addresses selected for the cards 8 serial ports. The last card in the chain has DIP 4 of CARD ID set to ON, all other Lynx and Quad port cards in the chain have DIP 4 of CARD ID set to off.

If the CARD ID is INCORRECTLY set then the Serial Solutions Software and the XENIX and UNIX drivers will incorrectly identify which serial port requires servicing and data will be lost! Be careful about the polarity of the chain cable, the ground from one card MUST be attached to the ground of the other. The ground is labelled GND and the two wires are different colours.


Figure 6-3. Valid Lynx 8 & Quad 4 Port CARD ID.

CARD ID:



Note: Default CARD ID = 0

MULTICARD ID:



Default CARD ID = 0

DIP 4 not used

Dip 1	Dip 2	Dip 3	4 Port	8 Port	Selected Card ID
On	On	On	0	0	Default 1 card installed
On	On	Off	0.5	1	Use on card number #2
On	Off	On	1.0	2	Use on card number #3
On	Off	Off	1.5	3	Use on card number #4
Off	On	On	2.0	4	Use on card number #5

Off	On	Off	2.5	5	Use on card number #6
Off	Off	On	3.0	6	Use on card number #7
Off	Off	Off	3.5	7	Use on card number #8

Mixing 4 Port and 8 Port Cards.

Any mix of Quad and Lynx port cards can be placed in a system. A pair of 4 port Quad cards can be treated as one eight port Lynx card, any odd 4 port card should be placed as the LAST card in the system with the highest ID. Do not let the IDs of four port cards overlap with the eight port cards. Thus if one 8 port and one 4 port card are both in a system the 8 port card, should have ID=0 and the four port should be set to ID=1.0 (not 0.5). The last card in the system, the Quad card, has CARD ID DIP4 set to ON (LAST CARD).


Two Card Systems.

When two Lynx/Quad cards are in use the first card has its CARD ID set to 0, it has CARD ID DIP4 set to OFF (NOT LAST). The second card has CARD ID DIP4 set to ON (LAST CARD).

Select the Serial port I/O addresses, e.g. the first card may have Ports 1-8 set to I/O address 0180-01B8 hex. The second cards may have Ports 1-8 set to I/O address 01C0-01F8 hex. Set the DIP switches for the each cards serial port address accordingly. Note: No two serial ports should have the same address.

Set the interrupt jumper for each port on each card to use the shared interrupt line. Select an I/O address for the Shared Interrupt Status Register, e.g. 03A0, set the DIP switches for the both cards to the SAME address. Select an interrupt line to use and set it on BOTH cards. E.g. SHRDIRQ on both cards sets to IRQ3, the default, or IRQ7. Now connect up the chaining links as below in figure 6-4.

Figure 6-4. Two Lynx Card Connection.




Three Card Systems.

When three Lynx/Quad cards are in use the first card has its CARD ID set to 0 and CARD ID DIP4 set to OFF (NOT LAST). The second card has its CARD ID set to 1, and CARD ID DIP4 set to OFF. The third card has its ID set to 2 and CARD ID DIP4 set to ON (LAST).

Select the Serial port I/O addresses, e.g. the first card may have Ports 1-8 set to I/O address 0180-01B8 hex. The second cards may have Ports 1-8 set to I/O address 01C0-01F8 hex. The third cards may have Ports 1-8 set to I/O address 0140-0178 hex. Set the DIP switches for the each cards serial port address accordingly. Note: No two serial ports have the same address.

Set the interrupt jumper for each port on each card to use the shared interrupt line. Select an I/O address for the Shared Interrupt Status Register, e.g. 03A0, set the DIP switches for all three cards to the SAME address. Select an interrupt line to use and set it on ALL THREE cards. E.g. SHRDIRQ on all cards sets to IRQ7. (The default) Now connect up the chaining links as below in figure 6-5.

Figure 6-5. Three Lynx Card Connection.




Four Or More Card Systems.

When four or more Lynx/Quad cards are in use the first card has its CARD ID set to 0 and CARD ID DIP4 set to OFF (NOT LAST). The second card has its CARD ID set to 1, the third card has its ID set to 2, etc. The second and third and all other cards each have a link across LAST and NO. The last (fourth) card in the system has its ID set to 3 and CARD ID DIP4 set to ON (LAST).

Select the Serial port I/O addresses, e.g. the first card may have Ports 1-8 set to I/O address 0180-01B8 hex. The second cards may have Ports 1-8 set to I/O address 01C0-01F8 hex. The third cards may have Ports 1-8 set to I/O address 0140-0178 hex, the fourth card Ports 1-8 set to I/O address 0100-0138 hex, the fifth card may have Ports 1-8 set to I/O address 0200-0238 hex etc. Note: No two serial ports have the same address.

Set the interrupt jumper for each port on each card to use the shared interrupt line. Select an I/O address for the Shared Interrupt Status Register, e.g. 03A0, set the DIP switches for ALL cards to the SAME address. Select an interrupt line to use and set it on ALL cards. E.g. SHRDIRQ on all cards sets to IRQ7. (The default). Now connect up the chaining links as below.

Figure 6-6. Four Or More Lynx Card Connection.



Multi Card Shared Interrupt Status Register.

The shared interrupt status register PRIORITY encoding system extends to each card in a multi Lynx card system. The ID of each card is used to form bits 3-6 of the byte read from the Shared Interrupt Status Register. Thus the SISR returns 0FF Hex if there are no interrupts pending, it returns 00 Hex if Lynx card#1 Serial Port 0 has an interrupt pending, it returns 07 Hex if card#1 Serial Port 8 has an interrupt pending. It returns 08 Hex if Lynx card#2 Serial Port 0 has an interrupt pending, it returns 0F Hex if card#2 Serial Port 8 has an interrupt pending. The full return value for up to six cards is given in Figure 6-7.

Reading the SISR does NOT clear the interrupt condition, that must be cleared by servicing the serial port chip in the normal way. The higher priority port will always override interrupts from the lower priority port. For best results place those devices with higher baud rates, or higher data rates (=same baud rate but more data) on the higher priority ports.

Figure 6-7. Multi Card Interrupt Priority.

Port	Priority	Shared Status Register Reads
No Interrupt	None	FF Hex= 256 decimal.
Port 1 Lynx#1	Highest	00 Hex= 0 decimal. CARD ID=0
Port 2 Lynx#1	Highest	01 Hex= 1 decimal.

Shared Interrupt Mechanisms

AT QUAD AND LYNX RS232

Port 3 Lynx#1	Highest	02 Hex= 2 decimal
Port 4 Lynx#1	Highest	03 Hex= 3 decimal
Port 5 Lynx#1	Highest	04 Hex= 4 decimal.
Port 6 Lynx#1	Highest	05 Hex= 5 decimal
Port 7 Lynx#1	Highest	06 Hex= 6 decimal.
Port 8 Lynx#1	Highest	07 Hex= 7 decimal

Port 1 Lynx#2	High	08 Hex= 8 decimal. CARD ID=1
Port 2 Lynx#2	High	09 Hex= 9 decimal
Port 3 Lynx#2	High	0A Hex= 10 decimal.
Port 4 Lynx#2	High	0B Hex= 11 decimal.
Port 5 Lynx#2	High	0C Hex= 12 decimal
Port 6 Lynx#2	High	0D Hex= 13 decimal.
Port 7 Lynx#2	High	0E Hex= 14 decimal.
Port 8 Lynx#2	High	0F Hex= 15 decimal.

Port 1 Lynx#3	Middle	10 Hex= 16 decimal. CARD ID=2
Port 2 Lynx#3	Middle	11 Hex= 17 decimal.
Port 3 Lynx#3	Middle	12 Hex= 18 decimal
Port 4 Lynx#3	Middle	13 Hex= 19 decimal
Port 5 Lynx#3	Middle	14 Hex= 20 decimal.
Port 6 Lynx#3	Middle	15 Hex= 21 decimal
Port 7 Lynx#3	Middle	16 Hex= 22 decimal.
Port 8 Lynx#3	Middle	17 Hex= 23 decimal

Port 1 Lynx#4	Middle	18 Hex= 24 decimal. CARD ID=3
Port 2 Lynx#4	Middle	19 Hex= 25 decimal.
Port 3 Lynx#4	Middle	1A Hex= 26 decimal
Port 4 Lynx#4	Middle	1B Hex= 27 decimal
Port 5 Lynx#4	Middle	1C Hex= 28 decimal.
Port 6 Lynx#4	Middle	1D Hex= 29 decimal.
Port 7 Lynx#4	Middle	1E Hex= 30 decimal.
Port 8 Lynx#4	Middle	1F Hex= 31 decimal

Port 1 Lynx#5	Low	20 Hex= 32 decimal. CARD ID=4
---------------	-----	-------------------------------

Port 2 Lynx#5	Low	21 Hex= 33 decimal.
Port 3 Lynx#5	Low	22 Hex= 34 decimal.
Port 4 Lynx#5	Low	23 Hex= 35 decimal
Port 5 Lynx#5	Low	24 Hex= 36 decimal.
Port 6 Lynx#5	Low	25 Hex= 37 decimal
Port 7 Lynx#5	Low	26 Hex= 38 decimal.
Port 8 Lynx#5	Low	27 Hex= 39 decimal

Port 1 Lynx#6	Low	28 Hex= 40 decimal. CARD ID=5
Port 2 Lynx#6	Low	29 Hex= 41 decimal.
Port 3 Lynx#6	Low	2A Hex= 42 decimal.
Port 4 Lynx#6	Low	2B Hex= 43 decimal.
Port 5 Lynx#6	Low	2C Hex= 44 decimal.
Port 6 Lynx#6	Low	2D Hex= 45 decimal.
Port 7 Lynx#6	Low	2E Hex= 46 decimal
Port 8 Lynx#6	Lowest	2F Hex= 47 decimal

CHAPTER 7

RS232 PORT

CABLING.

Introduction.

This chapter gives details of the 9 pin RS232 pin outs, cabling and connections, with information on how to connect the serial ports of two PCs and make a selftest loop back connector.

The RS232 Standard.

The RS232 standard is ancient in computer industry terms. Introduced in 1962, it is now widely established. RS232 is a slow speed, short distance, single ended transmission system (i.e. only one wire per signal). Typical RS232 maximum cable length is 50 feet with a maximum data rate of 20K bits per second.

Figure 7-1. RS232 Point To Point Connection.




RS232C Standard 1 Driver 1 Receiver	
Line Length	Max Data Rate
50 Feet = 15m	20 Kbits/sec

Serial Port Pin Outs.

The pinouts of the 9 and 25 pin Male D connectors are given below.

Figure 7-2. Serial Port RS232 Pin Outs.



9 Pin D Serial Port RS232 Cables.

To connect to the AT style RS232 Serial Port you will need a cable terminating in a 9 way female D connector. It is sound practice to use cables with screws fitted that will allow you to fasten the cable securely to the PC card.

In general, you will need to make up a "cross over" cable to correctly interface the PC to the RS232 port of another computer or device. Traditionally, making up the cross over cable has been considered a black art. However, provided you have the pin outs and handshake requirements of both sides of your RS232

connection, the cross over cable becomes a matter of common sense. The cross over cable is simply to ensure that the right signals going out of one RS232 port go into the appropriate lines of the other RS232 port.

9 Pin D Serial Port Connection To Another PC.

Suppose we want to connect the AT style 9 pin D Serial Port to the serial port of another IBM PC. See Figure 7-3.

- 1) Connect up the earth lines.
Line 5 of Serial Port 2 to lines 1 & 7 of the other PC.
This gives the two devices a common earth level.
- 2) Connect the Transmit and Receive lines together.
Line 3, TXD, Port 2 goes to line 3, RXD, of the other PC.
Line 2, RXD, Port 2 goes to line 2, TXD, of the other PC.
This allows each to receive the data transmitted by the other.
- 3) Connect up the Port 2 DTR line, pin 4 to the other PC DCD, pin 8 and CTS, pin 5, lines.
Also, connect up the other PC DTR line, pin 20 to the Port 2 DCD, pin 1 and CTS, pin 8, lines.
This allows the receiving device to signal when it can no longer accept data. The receiving device sets DTR false when it is unable to receive any more data. The sending device reads DTR on its CTS and DCD pins. It should stop sending when CTS goes false.
- 4) Connect up the Port 2 RTS line, pin 7, to the other PC DSR line, pin 6.
Also, connect up the other PC RTS line, pin 4, to the Port 2 DSR line, pin 6.
This RTS line is used to let the other device know that it

is ready for data exchange.

Figure 7-3. 9 Pin D Serial Port To Other PC Cable.


AT SERIAL PORT Side
Side.

Other PC SERIAL PORT


9 PIN D CONNECTOR

9 PIN D CONNECTOR

SCHEMATIC REPRESENTATION:



ACTUAL REPRESENTATION:




9 PIN D CONNECTOR


25 PIN D CONNECTOR

AT QUAD AND LYNX RS232
SCHEMATIC REPRESENTATION

RS232 Port Cabling



ACTUAL REPRESENTATION



9 Pin D Serial Port To A Modem.

If you are connecting a MODEM to a 9 pin D Serial Port then you will NOT need a cross over cable and a straight through cable connected as the 9 to 25 pin adapter given in Figure 7-5.

9 Pin D Serial Port Loop Back Connector.

A loop back connector can be used to echo RS232 data transmitted by a serial port back into its own RS232 receiver. In this way the function of the serial port can be tested.

For an AT style Serial Port use the a female 9 way connector wired as in Figure 7-4


Figure 7-4. 9 Pin D Serial Loop Back Connector.

9 PIN D CONNECTOR


25 PIN D CONNECTOR

RS232 Port Cabling

SCHEMATIC REPRESENTATION:



AT QUAD AND LYNX RS232



ACTUAL REPRESENTATION:





Figure 7-5. 9 To 25 Way Adapter.

This adapter cable makes the AT style 9 pin serial port, look like the standard PC 25 pin serial port. It is NOT a cross over cable!


9 Pin AT SERIAL PORT
9 Pin Female D Connector

25 Pin PC SERIAL PORT
25 Pin Male D Connector


AT QUAD AND LYNX RS232

RS232 Port Cabling

SCHEMATIC REPRESENTATION:



ACTUAL REPRESENTATION:



The Quad Cable Pinouts


The Quad cable consists of a 37 way female D connector attached to 4 25 way Male D connectors. Each of the cables carries 9 cores plus a sheath. Each of the 25 pin D connectors has 9 connections, based on the standard PC serial port configuration. Figure 7-7, on the next page shows the 37 way female connector pin numbers corresponding to each of the 4 separate port pin outs and pin functions. Each cable is approximately 1 metre long and is clearly marked as P1 for Port 1, P2 for Port 2 etc.

Figure 7-6. Quad Cable by 9 and 25 pin D Connector

37 way D connector Pinouts						
Port #1	Port #2	Port #3	Port #4	Pin Function	9 Pin	25 Pin
3	26	12	35	Transmitted Data (TXD)	3	2
2	25	11	34	Received Data (RXD)	2	3
21	7	30	16	Request To Send (RTS)	7	4
22	8	31	17	Clear To Send (CTS)	8	5
20	6	29	15	Data Set Ready (DSR)	6	6
5	28	14	37	Ground (GND)	5	7
1	24	10	33	Data Carrier Detect(DCD)	1	8
4	27	13	36	Data terminal Ready (DTR)	4	20
23	9	32	18	Ring Indicator (RI)	9	22

NOTE: Pin 19 on the 37 pin D connector is not used.

Figure 7-7. Pin outs of the AT Quad 4 Port RS232 38 pin D connector



NOTE: On the above diagram the # symbol followed by a number is used to notify a port on the cable. E.g. #4 means port 4, hence PIN36 - DTR#4 is pin 36 of the 37way connector, which corresponds to the DTR function on port 4.

The Lynx Card Octopus Cable Pinouts

The Lynx card octopus cable connects a 78 pin Male D connector to 8 nine way Male D connectors. Each of the cables has 9 cores plus a sheath. The sheath each of the 25 way D connectors is connected to the sheath of the 78 way D connector. Each of the 9 pin D connectors has 9 connections in the standard PC serial port configuration, see figure 7-8, below. Each cable is approximately 1 metre long and is clearly marked as P1 for Port 1, P2 for Port 2 etc.

Figure 7-8. Lynx Cable by 9 and 25 pin D Connector


78 way D connector Pinouts						
Port #1	Port #2	Port #3	Port #4	Pin Function	9 Pin	25 Pin
30	50	11	10	Transmitted Data (TXD)	3	2
55	17	37	56	Received Data (RXD)	2	3
51	31	12	14	Request To Send (RTS)	7	4
16	53	59	57	Clear To Send (CTS)	8	5
54	34	58	38	Data Set Ready (DSR)	6	6
68	69	70	71	Ground (GND)	5	7
35	33	39	18	Data Carrier Detect (DCD)	1	8
49	32	13	52	Data terminal Ready(DTR)	4	20
36	15	20	19	Ring Indicator (RI)	9	22

78 way D connector Pinouts						
Port #5	Port #6	Port #7	Port #8	Pin Function	9 Pin	25 Pin
40	2	63	64	Transmitted Data (TXD)	3	2
28	8	46	27	Received Data (RXD)	2	3
21	41	62	60	Request To Send (RTS)	7	4
25	4	9	45	Clear To Send (CTS)	8	5
5	42	29	26	Data Set Ready (DSR)	6	6
72	73	74	75	Ground (GND)	5	7
43	23	48	6	Data Carrier Detect (DCD)	1	8

22	3	61	1	Data terminal Ready(DTR)	4	20
44	24	47	7	Ring Indicator (RI)	9	22

NOTE: Pins 65,66,75 - 78 on the above connector are not used

Figure 7-8. Pin Outs of the 78 pin D connector on the AT Lynx 8 Port RS232



NOTE: On the above diagram the # symbol followed by a number is used to notify a port on the cable e.g. #4 means port 4, hence PIN47 DTR#4 is pin 47 of the 78way connector, which corresponds to the DTR function on port 4.

Index

16450 / 16550	1, 3, 5, 31, 117
adapter	137, 138
Add New Hardware	88, 89
address / addresses	61, 62, 95, 96, 117
asynchronous	5, 31
baud / baud rate	2, 3, 5, 31
BIOS	10, 37, 57, 61
bits	6, 32, 57, 63, 133
buffer	5
buffer / buffered	2, 3
buffer / buffered	31
buffered	5
cable	3, 57, 60, 63, 133, 134, 137, 138
Card ID	97
COM	89, 93
command	2, 62, 117
configuration	92, 97
connectors	60, 134
control panel	117
Control Panel	88, 93
cross over	134, 137, 138
CTS	2, 5, 31, 135
data word length	6, 32
DCD	2, 5, 31, 135
default	10, 36, 60, 96
device driver	2, 4
Device Manager	93
driver	88
DSR	2, 5, 31, 135
DTR	2, 5, 31, 135
emulation	2
FIFO	1, 3, 5, 31, 117
guarantee	2, 4, 6
handshake	1, 2, 134
IBM PC / AT / PS/2	135
Input/Output	95
installation	4, 57, 61, 63, 88, 91, 92, 96
Interrupt / Interrupts	64, 95, 96
interrupts	3

jumper	5, 12, 20, 31, 46, 57
last	97
loop back.....	3, 133, 137
LPT1 / LPT2 / LPT3.....	63
menu.....	88, 93
mode.....	2
modem.....	5, 31
multiple card.....	97
OS/2	2, 4, 6, 61, 117
parity	2, 3
pin outs.....	12, 133, 134
port / ports
...5, 10, 12, 20, 31, 36-38, 46, 57, 61-63, 64, 89, 91-93, 95-97, 117, 133-138	
Properties.....	93
protocol	2
receive.....	135
report.....	117
RI	5, 31
RS232.....	1, 5, 31, 57, 61, 62, 63, 133, 134, 137
RTS	2, 5, 31, 135, 137
RXD	5, 31, 135, 137
serial port	1-3, 5, 10-12, 20, 31, 36-38, 46, 57, 61-64, 89, 117, 133, 135-38
Serial Port.....	89
serial port address	5, 31, 62
Settings.....	88, 93
setup	10, 36, 61
Shared.....	96, 97
shared interrupt.....	3, 4, 95, 96
shared interrupt status register.....	96
speed	5, 31, 133
status	96
stop bits	57, 63
System.....	93
technical	4
TXD	5, 31, 135
utility disk.....	62
vector.....	20, 46
warning.....	97
Windows.....	2, 4, 6, 1, 3, 4, 10, 37, 61, 88, 89, 92, 97, 117