


ExpressCard 32 to 54mm Adaptor



***Control, Connect, Configure
Your Serial Devices!***

Many laptops have the wider 54mm ExpressCard slot. By adding a 34mm to 54mm adaptor to your ExpressCard it will eliminate movement in the slot ensuring reliable connectivity.



1. Extend the metal clip as shown on the picture above.



2. Connect the metal clip to the left side of the ExpressCard (the metal clip sits under the ExpressCard).



3. Now connect the plastic part to the other side of the ExpressCard.

There's so much more to Brainboxes

To enjoy the full benefits of Brainboxes, contact:

UK - **t.** +44 (0)151 220 2500 **f.** +44 (0)151 252 0446
e. sales@brainboxes.com **w.** www.brainboxes.com
Brainboxes Ltd. 18 Hurricane Drive,
International Business Park, Speke, Liverpool,
Merseyside L24 8RL

USA - **t.** +1 (727) 538 7710

Japan - **t.** +81-3-3833-2500
Brainboxes Japan. 1-2-8 Shinjyuku,
Shinjyuku-ku, Tokyo, 160-0022 Japan,

or visit **www.brainboxes.com**