

8.12 \$AA2

Description:

Reads device configuration.

Command Syntax:

<u>\$AA2[CS](CR)</u>	
\$	Delimiter character
<u>AA</u>	Address of the device to be configured in hexadecimal format (00 to FF)
2	Command to read the device configuration
<u>[CS]</u>	Checksum
(CR)	Carriage Return

Response:

Valid Command: !AATTBBFF[CS](CR)

Invalid Command: ?AA[CS](CR)

!	Delimiter for a valid command
?	Delimiter for an invalid command
<u>AA</u>	Address of the device (00 to FF)
<u>TT</u>	Device Type (40 for DIO Devices)
<u>BB</u>	Baud Rate of the device (See Baud Rate Settings)
<u>FF</u>	Configuration value (See Data Format Settings)
<u>[CS]</u>	Checksum
(CR)	Carriage Return

Examples:

Read the configuration of device 01.

Command: \$012(CR)

Response: !010400600(CR)