8.20 $AAM

Description:

Read the name of the device.

Command Syntax:

$AAM[CS](CR)	
$	Delimiter character
AA	Address of the device to be configured in hexadecimal format (00 to FF)
M	Command to read the device's name
[CS]	Checksum
(CR)	Carriage Return

Response:

Valid Command: !**AA(Data)[CS]**(CR)
Invalid Command: ?**AA[CS]**(CR)

!	Delimiter for a valid command
?	Delimiter for an invalid command
AA	Address of the responding device
(Data)	Name of the device
[CS]	Checksum
(CR)	Carriage Return

Examples:

Reads the device name. Command sent to the ED-588 and a valid response is returned with the device's name, ED-588.
Command: $01M(CR)
Response: !01ED-588(CR)