

8.23 @AA

Description:

Read the status of the digital I/O lines.

Command Syntax:

@AA[CS](CR)	
@	Delimiter character
AA	Address of the device to be configured in hexadecimal format (00 to FF)
[CS]	Checksum
(CR)	Carriage Return

Response:

Valid Command: **>DDDD[CS](CR)**

Invalid Command: **?AA[CS](CR)**

>	Delimiter for a valid command
?	Delimiter for an invalid command
DDDD	Four digit hexadecimal value representing the status of the I/O lines.
[CS]	Checksum
(CR)	Carriage Return

Examples:

Reads the digital input/output port status of the device's lines and returns F000 representing lines DOut 0-DOut 3 being low, DOut 4-DOut 7 being high and DIn0-DIn7 as being low.

Command: **@01(CR)**

Response: **>0203(CR)**