

\$aaRS

Applies to: All analogue input/output products

Description:

Command to reboot the device.

Note: The device can take a number of seconds to reboot. Close all connections to the device after sending the command. Connection can be re-established once the device has rebooted.

Command Syntax:

\$aaRS[CS](CR)	
\$	Delimiter character
aa	Address of the device to be reset in hexadecimal format (00 to FF)
RS	Command to reset the device
[CS]	Checksum
(CR)	Carriage Return

Response:

No response

Examples:

Send a command to reset the device. No response is expected.

Command: \$01RS(CR)

No Response